

Preface

Introduction to Materials

The CM680 is a high-performance general-purpose inverter, featuring a book-type design across the entire series to meet more installation area requirements. The product is equipped with rich hardware configurations and powerful software performance, supporting a variety of communication protocols and efficient control of various types of motors. It offers excellent drive performance and control functions, enabling the application of automated production equipment in industries such as metallurgy, lifting, machine tools, printing, wire drawing, glass, food, fans, and pumps.

This manual introduces the communication expansion card, including its overview, composition, dimensions, installation, electrical connections, and parameter configuration.

More Information

Document Name	Content Summary
CM680 Series General Purpose Inverter Quick Installation and Commissioning Manual	Introduces detailed content on product installation, wiring, commissioning, fault handling, function codes, fault codes, etc.
CM680 Series General Purpose Inverter Hardware Manual	Introduces the system composition, technical specifications, components, dimensions, optional accessories (installation accessories, cables, peripheral electrical components), expansion cards, and detailed content on daily maintenance and care, compliance with certifications and standards, etc.
CM680 Series General Purpose Inverter Installation Manual	Introduces the installation dimensions, space design, detailed installation steps, wiring requirements, cabling requirements, installation requirements for optional accessories, and detailed content on common EMC issue resolution suggestions, etc.
CM680 Series General Purpose Inverter Software Manual	Introduces the detailed content of the product's functional applications, communication, fault codes, function codes, etc.
CM680 Series General Purpose Inverter Communication Manual	Introduces the detailed content of the product communication expansion card's overview, composition, dimensions, installation, electrical connections, communication parameter configuration, fault codes, etc.

Version Change Record

Revision Date	Release Version	Change Content
2023-12	Ver 1.0	First release of the manual.
2023-04	Ver 1.1	Added methods for reading and writing inverter function codes using CANopen, etc.
2024-09	Ver 1.2	Modified some parameters and functions.

About Manual Acquisition

This manual is not shipped with the product. If you need to obtain the electronic PDF version, you can do so through the following methods:

Log in to the Changsha Riye Electric official website (www.cssunye.com), go to the "Download Center," search for the keyword, and download.

Warranty Statement

Under normal usage conditions, if the product malfunctions or is damaged, we provide warranty service within the warranty period. After the warranty period, repair fees will be charged.

Within the warranty period, the following situations causing product damage will incur repair fees.

- Damage caused by not operating the product according to the manual.
- Damage caused by fire, water, or abnormal voltage.
- Damage caused by using the product for non-standard functions.
- Damage caused by use beyond the specified product usage range.
- Secondary damage caused by force majeure (natural disasters, earthquakes, lightning strikes).

Service fees are calculated according to the manufacturer's unified standards. In case of a contract, the contract takes precedence. For detailed warranty information, please refer to the 'Product Warranty Card'.

Table of Contents

Preface	1
Precautions	9
1. Overview of Communication Protocols	11
2. PROFIBUS DP Communication	12
2.1. PRODUCT INFORMATION	12
2.1.1. External Dimensions	12
2.1.2. Interface Layout	12
2.2. INSTALLATION AND WIRING	14
2.2.1. Installation	14
2.2.2. Wiring	14
2.3. ELECTRICAL CONNECTIONS	15
2.4. COMMUNICATION DESCRIPTION	18
2.4.1. PROFIBUS Communication Key Points Description	18
2.4.2. Periodic Data Format	18
2.4.3. Non-periodic Data Format	19
2.5. COMMUNICATION CONFIGURATION	20
2.5.1. Configuration Settings	20
2.5.2. Configuring Periodic Communication	28
2.5.3. Configuring Non-Periodic Communication	30
2.6. FAULT INFORMATION	37
2.6.1. Periodic Fault Codes	37
2.6.2. Non-periodic Fault Code	38
2.6.3. Obtaining Diagnostic Information	39

2.6.4. Erasing Fault Codes	41
3. PROFINET Industrial Ethernet Communication	43
3.1. PRODUCT INFORMATION	43
3.1.1. External Dimensions	43
3.1.2. Interface Layout	43
3.2. INSTALLATION AND WIRING	44
3.2.1. Installation	45
3.2.2. Wiring	45
3.3. COMMUNICATION DESCRIPTION	46
3.3.1. Key Points of PROFINET Communication	46
3.3.2. Data Transmission Format	46
3.3.3. PZD Area Data Description	47
3.3.4. Master Station Data Transmission Description	47
3.3.5. Inverter Response Data Description	47
3.4. COMMUNICATION CONFIGURATION	48
3.4.1. Configuration Settings	48
3.4.2. Configuring Periodic Communication	59
3.4.3. Configuring Non-Periodic Communication	62
3.5. FAULT INFORMATION	63
3.5.1. Periodic Fault Codes	63
3.5.2. Non-periodic Fault Code	64
3.5.3. Module Information	64

3.5.4. Diagnostic Buffer Fault Meaning and Handling	65
3.5.5. Non-periodic Read or Erase Fault Code	65
3.6. MRP FUNCTION DESCRIPTION	67
3.6.1. MRP Ring Network	67
3.6.2. MRP Configuration	68
4. EtherNet/IP Industrial Ethernet Communication	70
4.1. PRODUCT INFORMATION	70
4.1.1. External Dimensions	70
4.1.2. Interface Layout	70
4.2. INSTALLATION AND WIRING	71
4.2.1. Installation	71
4.2.2. Wiring	72
4.3. COMMUNICATION DESCRIPTION	72
4.3.1. EtherNet/IP Communication Key Points	72
4.3.2. Data Transmission Format	73
4.3.3. Master Station Data Transmission Description	73
4.3.4. Inverter Response Data Description	73
4.4. COMMUNICATION CONFIGURATION	74
4.4.1. Configuration Settings	74
4.4.2. Configuring Non-Periodic Communication	74
4.5. FAULT INFORMATION	76
4.5.1. Periodic Fault Codes	

76	
4.5.2. Reading and Erasing Fault History	77
5. EtherCAT Industrial Ethernet Communication	79
5.1. PRODUCT INFORMATION	79
5.1.1. External Dimensions	79
5.1.2. Interface Layout	79
5.2. INSTALLATION AND WIRING	81
5.2.1. Installation	81
5.2.2. Wiring	81
5.3. COMMUNICATION DESCRIPTION	81
5.3.1. EtherCat Communication Key Points	81
5.3.2. Periodic Data Read/Write Description	82
5.3.3. Non-periodic Data Read/Write Description	84
5.4. COMMUNICATION CONFIGURATION	89
5.4.1. Configuration Settings	90
5.4.2. Configuring Periodic Communication	95
5.4.3. Configuring Non-Periodic Communication	105
5.5. FAULT INFORMATION	116
5.5.1. Periodic Fault Codes	116
5.5.2. Non-periodic Fault Code	116
5.5.3. Obtaining Diagnostic Information	116
5.5.4. Non-periodic Read or Erase Fault Code	

	118
6. CANopen Communication	122
6.1. PRODUCT INFORMATION	122
6.1.1. External Dimensions	122
6.1.2. Interface Layout	122
6.2. INSTALLATION AND WIRING	124
6.2.1. Installation	124
6.2.2. Wiring	124
6.3. COMMUNICATION DESCRIPTION	124
6.3.1. Key Points of CANopen Communication	124
6.3.2. CANopen Communication Protocol	126
6.3.3. Communication Sub-Protocol	132
6.3.4. Custom Protocol One	145
6.3.5. Custom Protocol Two	149
6.3.6. CiA 402	151
6.4. CANOPEN INVERTER FUNCTION DEBUGGING	152
6.4.1. CANopen Select CiA 402 Protocol	153
6.4.2. CANopen Select Inverter Manufacturer Custom Protocol	153
6.4.3. Analog AIO and DIO	154
6.5. CANOPEN FAULT CODES	156
6.6. COMMUNICATION CONFIGURATION	159
6.6.1. Configuration Settings	159

6.6.2. Configuring Periodic Communication	160
6.6.3. Configuring Non-Periodic Communication	160
7. Appendix: General Periodic Fault Codes	162
8. Appendix: Modbus Communication	165
8.1. COMMUNICATION INTRODUCTION	165
8.2.RS485 CONNECTION TOPOLOGY	165
8.3.COMMUNICATION TRANSMISSION METHODS	165
8.4.COMMUNICATION DATA FRAME STRUCTURE	166
8.5.RELEVANT PARAMETERS	167
8.6.COMMUNICATION PARAMETER ADDRESSES	169

Precautions

Safety Statement

1. This chapter explains the safety precautions necessary for the proper use of this product. Before using this product, please read the user manual and correctly understand the information related to safety precautions. Failure to comply with the matters specified in the safety precautions may result in death, serious injury, or equipment damage.
2. The 'Danger', 'Warning', and 'Caution' items in the manual do not represent all safety matters that should be observed, but are provided as a supplement to all safety precautions.
3. This product should be used in an environment that meets the design specifications; otherwise, it may cause malfunctions. Any functional abnormalities or component damage caused by non-compliance with these specifications are not covered by the product warranty.
4. Our company will not assume any legal responsibility for personal injuries or property damage caused by non-compliance with the content of this manual or improper operation of the product.

Definition of Safety Levels

In this manual, safety precautions are divided into the following two categories:



Danger: Situations where failure to follow the required procedures can result in serious injury or even death;



Caution: Situations where failure to follow the required procedures can result in moderate injury or minor injury, as well as equipment damage;

Please read this chapter carefully when installing, debugging, and maintaining this system, and strictly follow the safety precautions outlined in this chapter. The company will not be liable for any injuries or losses resulting from non-compliance with the operating procedures.

Safety Precautions

Usage Phase	Safety Level	Matters
Before Installation	 Danger	If you find that the control system is waterlogged, parts are missing, or components are damaged upon unpacking, do not install!
	r	If the packing list does not match the actual items, do not install!
During installation	 Caution	Handle with care when moving to avoid the risk of damaging the equipment! Do not touch the components of the control system to avoid the risk of static damage!
	 Danger	Only trained personnel with knowledge of electrical equipment and electrical expertise should operate. Non-professionals are strictly prohibited from operating!
When wiring	r	Do not allow wire ends or screws to fall into the drive, as this can cause damage to the drive!
	 Caution	Please install the drive in a location with minimal vibration and avoid direct sunlight.
When wiring	 Danger	Installation must be performed by a professional electrical engineer; otherwise, unexpected dangers may occur!
	r	Before wiring, ensure that the power supply is in a zero-energy state to avoid the risk of electric shock! Please ensure that the inverter is properly and correctly grounded according to standards to avoid the risk of electric shock!

Usage Phase	Safety Level	Matters
	 Caution	<p>Please follow the steps specified in the Electrostatic Discharge (ESD) prevention measures and wear an ESD wrist strap when performing wiring and other operations to avoid damaging the equipment or internal circuits of the product.</p> <p>When wiring the control circuit, please use twisted pair shielded wire and connect the shield to the product's grounding terminal for grounding; otherwise, it may cause abnormal operation of the product.</p>
Before Powering On	 Danger	<p>Before powering on, please ensure that the product is installed properly, the wiring is secure, and the motor device is allowed to restart.</p> <p>Before powering on, please confirm that the power supply meets the product requirements to avoid damaging the product or causing a disaster!</p> <p>Do not open the product cabinet door or protective cover, touch any wiring terminals, or remove any components or parts while the power is on, as there is a risk of electric shock!</p>
	 Caution	<p>The inverter must be covered with the cover before power can be applied; otherwise, there is a risk of electric shock!</p> <p>Wire according to the circuit connection methods provided in this manual; otherwise, accidents may occur!</p>
After power-on	 Danger	<p>Do not open the cover after power-on. Otherwise, there is a risk of electric shock!</p> <p>Do not touch any input or output terminals of the inverter. Otherwise, there is a risk of electric shock!</p>
	 Caution	<p>If parameter identification is required, be aware of the danger of injury from the rotating motor; otherwise, accidents may occur!</p> <p>Do not arbitrarily change the manufacturer's parameters of the inverter; otherwise, it may cause damage to the equipment!</p>
During operation	 Danger	<p>Non-professional technical personnel should not test signals during operation; otherwise, it may cause personal injury or equipment damage!</p> <p>Do not touch the cooling fan or discharge resistor to test the temperature; otherwise, it may cause burns!</p>
	 Caution	<p>During inverter operation, avoid dropping objects into the equipment, as this can cause damage to the device!</p> <p>Do not use contactors to control the start and stop of the drive, as this can cause damage to the equipment!</p>
During maintenance	 Danger	<p>Do not perform repairs or maintenance on the inverter without professional training, as this can result in personal injury or equipment damage!</p> <p>Do not perform repairs or maintenance on the equipment while it is energized, as this poses an electric shock hazard!</p> <p>Ensure that the inverter's input power has been disconnected for at least 10 minutes before performing maintenance or repairs on the drive, as residual charges in the capacitors can cause injury!</p> <p>All pluggable modules must be inserted or removed with the power off!</p> <p>After replacing the communication module, parameter settings and checks must be performed.</p>

1. List of Communication Protocols

Supported Communication Protocols			Communication Hardware	
PROFIBUS DP Communication			External Communication Expansion Module	EMH-DP Communication Expansion Card
PROFINET Communication	Industrial	Ethernet		EMH-PN Communication Expansion Card
EtherNet/IP Communication	Industrial	Ethernet		EMH-EN Communication Expansion Card
EtherCAT Communication	Industrial	Ethernet		EMH-EC Communication Expansion Card
CANopen Communication				EMH-OP Communication Expansion Card

2. PROFIBUS DP Communication

2.1. Product Information

The EMH-DP Communication Expansion Card is a PROFIBUS fieldbus adapter card that complies with the international standard for PROFIBUS-DP fieldbus. This card is installed on the CM680 Inverter to enable communication with PROFIBUS master station devices, making the inverter a slave station of PROFIBUS DP, accepting control from the master station.

2.1.1. Physical Dimensions

Physical dimensions of the PROFIBUS Communication Expansion Card: PCB length 95mm, width 37mm, mounting hole diameter 3.5mm.



Figure 1 Physical Dimensions of the EMH-DP Communication Expansion Card

2.1.2. Interface Layout

The hardware layout of the EMH-DP Communication Expansion Card is shown in Figure 2. Pin Header X3 is used for connecting to the inverter and is located on the back of the EMH-DP Communication Expansion Card. The EMH-DP Communication Expansion Card provides a 9-pin D-type connector for PROFIBUS communication. Detailed descriptions of each hardware component are provided in Table 1.




Figure 2 EMH-DP Communication Expansion Card Interface Layout

Table 1 EMH-DP Communication Expansion Card Interface Description

Diagram Name	Hardware Name	Function Description
X1	Socket	UART Interface: Print Operation Information
X2	9-pin D-type Connector	For Module Connection to PROFIBUS Network, Refer to Figure 1.3 Description
X3	Board-to-Board Socket	For Connection to Inverter
X4	Socket	For Firmware Download and Debugging
D1, D2, D3, D4	LED Indicator Light	Used to indicate the operating status, refer to Table 1.2 for details

1. PROFIBUS-DP Communication Interface

The EMH-DP Communication Expansion Card uses a standard DB9 connector to connect with the PROFIBUS master station, and its pin signal definitions follow the SIEMENS DB9 connector standard distribution. As shown in the following figure:




Figure 3 EMH-DP Communication Expansion Card DP Communication Interface Description

2. LED Indicator Light

Table 2 EMH-DP Communication Expansion Card LED Indicator Light Description

Diagram Name	Indicator Light	Indicator Light Status		Function Description
D1	PROFIBUS Communication Status Indicator Light	Red Light	Constantly On	Indicates no communication between the module and the PROFIBUS master station (check PROFIBUS cable connections and station number)
			Off	Indicates normal communication between the module and the PROFIBUS master station
D2	Inverter communication status indicator light	Red Light	Constantly On	Communication timeout with the inverter
			Flashing	Abnormal communication with the inverter (interference exists, poor connection, etc.), communication format error (register address error, data error, etc.)
			Off	Normal communication with the inverter
D3	Program run	Green	Constantly	Main program running normally

	status indicator light	light	On	
			Off	Main program not started properly
D4	Hardware power indicator light	Green light	Constantly On	Module powered on normally
			Off	Module not powered on

2.2. Installation and Wiring

2.2.1. Installation

The EMH-DP Communication Expansion Card is designed to be embedded in the CM680 Inverter. Before installation, please disconnect the power supply to the inverter, wait for about 10 minutes, and ensure that the inverter's charging indicator light is completely off before proceeding with the installation. After inserting the EMH-DP Communication Expansion Card into the inverter, please secure the corresponding screws to prevent poor contact between the board and the signal socket. The installation diagram is shown in Figure 4.




Figure 4 EMH-DP Communication Expansion Card Installation Diagram

2.2.2. Wiring

The wiring diagram for the PROFIBUS DP bus is shown in Figure 5. Terminal matching resistors must be connected at both ends of the PROFIBUS bus. Adjust the DIP switch according to the markings on the terminal block. Failure to connect or insufficient terminal resistors can affect communication quality, leading to unstable communication.




Figure 5 Schematic Diagram of PROFIBUS DP Bus Wiring

The PROFIBUS-DP communication rate ranges from 9.6 kbps to 12 Mbps, and the transmission line length must be determined based on the transmission rate, with a transmission distance range of 100m to 1200m. The communication rates supported by the EMH-DP Communication Expansion Card and the communication distances at each rate are shown in Table 3.

Table 3 Maximum Cable Length for Different PROFIBUS-DP Transmission Rates

Communication Rate (bps)	9.6k	19.2k	93.75k	187.5k	500k	1.5M	3M	6M	12M
Length (m)	1200	1200	1200	1000	400	200	100	100	100

2.3. Electrical Connection

Bus Cable Description

It is recommended to use dedicated Profibus DP bus cables. Cable parameters are shown in the table below.

Table 4 Cable Parameters

Parameter	Description
Conductor	1 pair (2×22AWG) solid copper wire
Insulation Jacket Color	Green, Red
Shielding	Aluminum foil tape + tinned copper wire braid
Jacket Material	PVC
Appearance	Purple




Fig. 6 Schematic Diagram of Bus Cable Inner Structure

Bus Terminal Description:

It is recommended to use SIEMENS Profibus DP dedicated connector, model: 6ES7 972-0BB12-0XA




Fig. 7 Schematic Diagram of Bus Connection Terminal Layout

Bus Connection Steps

1. Remove the outer sheath of the cable, and leave the length according to the dimensions below.




Fig. 8 Cable Length Reserve Diagram (Unit: mm)

2. Use a No. 1 flathead screwdriver to open the bus connector terminal cover.




Fig. 9 Opening the Bus Connector Terminal Cover

3. Use a No. 1 flathead screwdriver to secure the cable to the connector installation position, ensuring that the shielding layer is in tight contact with the shielding layer metal plate, green cable connects to A, red cable connects to B, as shown in the figure below.




Figure 10 Shield Layer in Contact with Metal Plate

4. After covering the connector cover and tightening the screws on the cover, insert the CM680-PROFIBUS corresponding DB9 port, and use a screwdriver to tighten the fixing screws on both sides to prevent loosening.

Note: When installing the Profibus DP bus, ensure that the screws on both sides of the Siemens terminal are securely connected to the EMH-DP module; otherwise, communication may fail or the communication quality may decrease.

2.4. Communication Description

2.4.1. Key Points of PROFIBUS Communication

1. When using the EMH-DP communication expansion card, it is necessary to set the communication decoding method of the CM680. Set the F8-19 register to 0 via the operation panel, and set the F8-07 register to 0 or 1 according to the actual decoding method used.

2. When setting the inverter command, the F0-05 register of the CM680 must be set to 5.

3. When setting the inverter frequency, the F0-06 register of the CM680 must be set to 8.

4. The device address for PROFIBUS communication on the EMH-DP Communication Expansion Card is set in the F8-11 register. After setting, the module must be restarted for the changes to take effect.

5. During non-periodic communication, a new non-periodic read/write operation must not be initiated until the previous one is completed. The interval between two non-periodic communications should be no less than 100ms to avoid affecting the response of periodic communication.

2.4.2. Periodic Data Format

Through PZD area data, the master station can update and read inverter data in real-time and perform periodic data exchange. The communication address is configured by the user during setup.

The EMH-DP Communication Expansion Card provides multiple Modules to transmit PZD data of different lengths. Users select a specific Module for configuration during setup according to their needs. The supported data length for each data format is listed in the table below:

Table 5 Supported Data Length for Each Data Format

Module	Data Length
PZD-2/3	Cyclic Write (master->slave): PZD1~PZD2 Cyclic Read (slave->master): PZD1~PZD3
PZD-6/6	Cyclic Write (master->slave): PZD1~PZD6 Cyclic Read (slave->master): PZD1~PZD6
PZD-10/10	Cyclic Write (master->slave): PZD1~PZD10 Cyclic Read (slave->master): PZD1~PZD10
PZD-16/16	Cyclic Write (master->slave): PZD1~PZD16 Cyclic Read (slave->master): PZD1~PZD16

When configuring the newly installed communication expansion card, each PZD has a default address, as follows:

- PZD1 (master->slave): 24576 (0x6000), Control Command
- PZD2 (master->slave): 24578 (0x6002), Target Frequency
- PZD1 (slave->master): 8448 (0x2100), Errors and Warnings (Fixed Address)
- PZD2 (slave->master): 24832 (0x6100), Current Status
- PZD3 (slave->master) : 24834 (0x6102), actual frequency

- Other addresses: 2096 (0x0830), reserved address, unused PZD should be set to this address to avoid affecting other functions

2.4.3. Non-periodic data format

Non-periodic interaction uses slot-index addressing to determine the format of the message data area. To facilitate user operations on consecutive registers of the inverter, the following non-periodic read/write format is defined, with the index set to 100.

1. Non-periodic write

When executing a non-periodic write command, the data area must include the starting address of the register, length, and value, with the function code fixed at 0x10, indicating a write command. The specific format is as follows:

Table 6 Non-periodic write data format

	Function Code	Register Address	Register Length	Data
Data Length	1 Byte	2 Byte	1 Byte	(Register Length * 2) Byte
Example	0x10	0x1010	0x02	0x01020304

The total length of the data area for non-periodic write values is at least 6 Byte and at most 24 Byte.

2. Non-periodic Read Value

In the non-periodic read value request message, the data area is empty and cannot transmit the register address to be read. A non-periodic write value command must be sent first to cache the register address in the module. The function code for this non-periodic write address command is fixed at 0x03, and the data area length is fixed at 3 Byte. The specific format is as follows:

Table 7 Non-periodic Read Data Format

	Function Code	Register Address
Data Length	1 Byte	2 Byte
Example	0x03	0x1010

After executing the non-periodic write address command, send the non-periodic read value command. The read value request message includes the register length to be read, and the data area is empty. The data area of the response message is the register value. The format of the data area in the response message is as follows:

Table 8 Format of the Response Message Data Area

	Data
Data Length	(Register Length * 2) Byte
Example	0x01020304

2.5. Communication Configuration

Taking the Siemens S7-1200 series PLC as an example, configure the PLC to establish PROFIBUS communication with the module.

2.5.1. Configure Configuration


1. Create a project

Double-click to open the TIA Portal software, select 'Create New Project', and the following interface will appear. Choose the save path and project name, then click 'Create'.




After creation, click 'Project View' to enter the main interface. In the 'Hardware Catalog' on the right, select the actual PLC model being used, for example, S7-1214. Double-click to see the PLC in the configuration page.


CM680 Inverter Communication Manual PROFIBUS DP Communication



Click on the PLC, enter the 'Device View' page, and in the properties bar, you can configure the IP address and other information of the PLC, which can be modified according to the actual situation.




In the hardware catalog, select the CM1243-5 communication module, add it next to the PLC, click on this communication module, and you can configure its PROFIBUS address and other parameters.



This completes the establishment of the master station.


2. Install GSD File

If the GSD file has not been installed before, it needs to be installed. In 'Options', select 'Manage General Station Description (GSD) Files'.




3. Configure Slave Station

Return to the “Device and Network” — “Network View” interface, in the “Hardware Catalog” on the right, find the CM680 position under Other Field Devices — PROFIBUS DP — Drive — SUNYE, and double-click to add the module.




Click on “Unassigned” on the module in the “Device and Network” interface to assign the master station system to the module. Click on the DP connection line to configure parameters such as the DP transmission baud rate.



CM680 Inverter Communication Manual PROFIBUS DP Communication


Select the slave station, and in “Properties” -> “General” -> “PROFIBUS Address” -> “Parameters,” set the PROFIBUS device slave address. The slave address must be different from the master address.



2.5.2. Configure Periodic Communication

1. Configure Module


Select the slave station, switch to the “Device View,” and under “Hardware Catalog” -> “Module,” double-click to select the data length to be configured for the slave station. The configured module will be added in the device view. After adding the module, you can modify the input/output mapping in the PLC by editing the “I Address” and “Q Address”.



2. Configure PZD

Through PZD area data, the master station can real-time modify and read inverter data, and perform periodic data exchange.


Select the slave station, under “Properties” -> “General” select “Device Specific Parameters”, set the register address for user-defined periodic data. PZDx(Master->Slave) indicates the address where the master station writes to the slave station, and PZDx(Slave->Master) indicates the address where the master station reads from the slave station, in decimal format. Refer to section 3.2 for default addresses.



After configuration is complete, download the configuration, and the PLC and module will automatically perform periodic data exchange.

3. Download Configuration and Ladder Diagram

Save the configured network, set the computer's IP address to the same subnet as the PLC (note that it should not conflict with the IP addresses of the slave stations in the configuration, or you can set the PC to automatically obtain an IP address), compile, click download, select the interface, and then click 'Start Search'. Select the detected PLC, and then click download.



2.5.3. Configure Non-periodic Communication

1. Example of Non-periodic Write

Add a data block FB_control, and allocate some variables as follows:

WR1_LEN represents the byte length of the send array; in the example below, it is 6 bytes.

The WR1_Record array is filled with the corresponding content according to the non-periodic interaction format. In the example below, the WR1_Record array contains the 6 bytes to be sent, with the following meanings:

WR1_Record[0]: Function code 0x10 indicates write.

WR1_Record[1] and WR1_Record[2]: indicate that the starting address of the registers to be written is 0xF00E.

WR1_Record[3]: indicates that the number of consecutive registers to be written is 1.

WR1_Record[4] and WR1_Record[5]: indicate that the data to be written to the starting register address (0xF00E) is 0x1499.

CM680 Inverter Communication Manual PROFIBUS DP Communication


名称	数据类型	起始值	保持	从 HMI/OPC...	从 H...	在 HMI ...	设定值	监控	注释
Static									
WR1_EN	Bool	false		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_DONE	Bool	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_BUSY	Bool	false		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_ERR	Bool	false		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_LEN	Byte	6		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_STATUS	DWord	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record	Array[0..23] of Byte			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[0]	Byte	16#10		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[1]	Byte	16#F0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[2]	Byte	16#0E		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[3]	Byte	16#01		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[4]	Byte	16#14		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[5]	Byte	16#99		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[6]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[7]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[8]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[9]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[10]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[11]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[12]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[13]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[14]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[15]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[16]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
WR1_Record[17]	Byte	16#0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

Add the following program in the main program block:

Function block name: WRREC


ID: The ID of the module configured during PROFIBUS module configuration

INDEX: 100



程序段 2 :

注释



Recompile the PLC program and download it to the PLC. Switch to online mode. Set “FB_control.WR1_EN” to 1, which will trigger a non-periodic write action.

Monitor the FB_control data block online to see the execution results. “FB_control.WR1_Done” being TRUE indicates successful execution, “FB_control.WR1_ERR” being TRUE indicates an execution error, with the error code stored in “FB_control.WR1_STATUS”. Refer to Section 5.2 for specific meanings.

名称	数据类型	起始值	监视值	保持
▼ Static				<input type="checkbox"/>
■ WR1_EN	Bool	false	FALSE	<input type="checkbox"/>
■ WR1_DONE	Bool	false	TRUE	<input type="checkbox"/>
■ WR1_BUSY	Bool	false	FALSE	<input type="checkbox"/>
■ WR1_ERR	Bool	false	FALSE	<input type="checkbox"/>
■ WR1_LEN	Byte	6	16#06	<input type="checkbox"/>
■ WR1_STATUS	DWord	16#0	16#0000_0000	<input type="checkbox"/>
■ ▼ WR1_Record	Array[0..23] of Byte			<input type="checkbox"/>
■ WR1_Record[0]	Byte	16#10	16#10	<input type="checkbox"/>
■ WR1_Record[1]	Byte	16#F0	16#F0	<input type="checkbox"/>
■ WR1_Record[2]	Byte	16#0E	16#0E	<input type="checkbox"/>
■ WR1_Record[3]	Byte	16#01	16#01	<input type="checkbox"/>
■ WR1_Record[4]	Byte	16#14	16#14	<input type="checkbox"/>
■ WR1_Record[5]	Byte	16#99	16#99	<input type="checkbox"/>
■ WR1_Record[6]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[7]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[8]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[9]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[10]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[11]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[12]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[13]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[14]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[15]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[16]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[17]	Byte	16#0	16#00	<input type="checkbox"/>
■ WR1_Record[18]	Byte	16#0	16#00	<input type="checkbox"/>

2. Non-periodic Read Value

Add a data block FB_control, and allocate some variables as follows:

WR2_Record array: Enter the function code and address for reading

WR2_Record[0] : Read function code 0x03

WR2_Record[1] and WR2_Record[2]: The register address to be read is 0xF00E

WR2_LEN: The length of the data to be written is 3 bytes, i.e., WR_Record[0]~[2].

RD2_MLEN: The length of the data to be read is 2 bytes, i.e., the data of one register.

RD2_Record array: The data read is stored in this array.


CM680 Inverter Communication Manual PROFIBUS DP Communication

9			WR2_EN	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
10			WR2_DONE	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
11			WR2_BUSY	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
12			WR2_ERR	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
13			WR2_LEN	Byte	3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
14			WR2_STATUS	DWord	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
15			▼ WR2_Record	Array[0..23] of Byte		<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
16			WR2_Record[0]	Byte	16#03	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
17			WR2_Record[1]	Byte	16#F0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
18			WR2_Record[2]	Byte	16#0e	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
19			WR2_Record[3]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
20			WR2_Record[4]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
21			WR2_Record[5]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
22			WR2_Record[6]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
23			WR2_Record[7]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
24			WR2_Record[8]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
25			WR2_Record[9]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
26			WR2_Record[10]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
27			WR2_Record[11]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
28			WR2_Record[12]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
29			WR2_Record[13]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
30			WR2_Record[14]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
31			WR2_Record[15]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
32			WR2_Record[16]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
33			WR2_Record[17]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
34			WR2_Record[18]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
35			WR2_Record[19]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
36			WR2_Record[20]	Byte	16#0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Add the following program in the main program block:


Function block: WRREC is used to write the starting address of the registers to be read


Function Block: RDREC is used to save the data starting from the first address of the read registers.



程序段 4 :


注释





程序段 6 :

注释




Recompile the PLC program and download it to the PLC. Set 'FB_control.WR2_EN' to 1 to trigger the write read address. When 'FB_control.WR2_Done' is TRUE, it indicates that the write read address was successful. Then set 'FB_control.RD2_EN' to 1, which will trigger the non-periodic read value action. Monitor the 'FB_control' data block online to see the execution results. 'FB_control.RD2_Done' being TRUE indicates successful execution, and 'Error' being TRUE indicates an execution anomaly. The error code is stored in 'FB_control.RD2_STATUS'; refer to Section 5.2 for specific meanings.

名称	数据类型	起始值	监视值	保持
▼ Static				<input type="checkbox"/>
WR1_EN	Bool	false	FALSE	<input type="checkbox"/>
WR1_DONE	Bool	false	TRUE	<input type="checkbox"/>
WR1_BUSY	Bool	false	FALSE	<input type="checkbox"/>
WR1_ERR	Bool	false	FALSE	<input type="checkbox"/>
WR1_LEN	Byte	6	16#06	<input type="checkbox"/>
WR1_STATUS	DWord	16#0	16#0000_0000	<input type="checkbox"/>
▶ WR1_Record	Array[0..23] of Byte			<input type="checkbox"/>
WR2_EN	Bool	false	FALSE	<input type="checkbox"/>
WR2_DONE	Bool	false	TRUE	<input type="checkbox"/>
WR2_BUSY	Bool	false	FALSE	<input type="checkbox"/>
WR2_ERR	Bool	false	FALSE	<input type="checkbox"/>
WR2_LEN	Byte	3	16#03	<input type="checkbox"/>
WR2_STATUS	DWord	16#0	16#0000_0000	<input type="checkbox"/>
▶ WR2_Record	Array[0..23] of Byte			<input type="checkbox"/>
RD2_EN	Bool	false	FALSE	<input type="checkbox"/>
RD2_DONE	Bool	false	TRUE	<input type="checkbox"/>
RD2_BUSY	Bool	false	FALSE	<input type="checkbox"/>
RD2_ERR	Bool	false	FALSE	<input type="checkbox"/>
RD2_STATUS	DWord	16#0	16#0000_0000	<input type="checkbox"/>
RD2_MLEN	Byte	2	16#02	<input type="checkbox"/>
▼ RD2_Record	Array[0..23] ...			<input type="checkbox"/>
RD2_Record[0]	Byte	0	16#14	<input type="checkbox"/>
RD2_Record[1]	Byte	16#0	16#99	<input type="checkbox"/>
RD2_Record[2]	Byte	16#0	16#00	<input type="checkbox"/>
RD2_Record[3]	Byte	16#0	16#00	<input type="checkbox"/>
RD2_Record[4]	Byte	16#0	16#00	<input type="checkbox"/>
RD2_Record[5]	Byte	16#0	16#00	<input type="checkbox"/>
RD2_Record[6]	Byte	16#0	16#00	<input type="checkbox"/>


3. Explanation of Encapsulated Non-periodic Read/Write Function Blocks

To allow users to perform non-periodic read/write operations without needing to understand Modbus messages, the manufacturer has encapsulated two non-periodic read/write function blocks for user reference.

DP_WRITE function block: Achieves non-periodic writing, ID: represents the moduleID to be written, ADDR: represents the address of the function code to be written, LEN: represents the number of registers to be written, DATA: array of values to be written to the registers.



DP_READ function block: A function block to achieve non-periodic reading, ID: represents the module ID to be written, ADDR: represents the address of the function code to be read, MLEN: represents the number of registers to be read, DATA: array to store the values read from the registers.



2.6. Fault Information

2.6.1. Periodic Fault Code

In the PZD area of periodic communication, the PZD1 sent from the slave station to the master station is fixed to indicate error and alarm information, allowing users to obtain the latest status through periodic communication. In addition to the diagnostic information of the inverter itself, the communication status between the module and the inverter must also be included, allowing users to obtain the cause of errors. Detailed fault status codes are listed in the table below:

Table 9 PROFIBUS Periodic Fault Status Codes

Diagnostic Classification	Status Code
Inverter Body	200 Communication Error (Message Abnormality)
Diagnostic Information (Register)	201 Communication Error (Timeout Abnormality)

Address: 0x2100)	202	Address Error
	203	Parameter Exceeds Threshold

2.6.2. Non-periodic Fault Code

When executing non-periodic communication, the STATUS parameter in the function block is used to return the command execution result, with a data type of DWORD (4 bytes). The data format and meaning are already defined in the TIA software. In addition to the standard definition, the following error codes have the following meanings:

Table 10 PROFIBUS Non-periodic Fault Status Codes

Function _ Num	Error_ Decode	Error_ Code_1	Error_ Code_2	Meaning
0xC0	0x80	0xB8	0x01	Non-periodic Message Function_Num Error (Module only supports 0x5E, 0x5F).
0xC0	0x80	0xA2	0x00	Non-periodic Data Length Exceeds Limit (0 bytes <= Data Length <= 64 bytes).
0xDE	0x80	0xB0	0x00	Invalid Data Record Number (Index=100, or Index=101).
0xDE	0x80	0xB8	0x02	Non-periodic Read Value Data Length Exceeds Limit (2 bytes <= Data Length <= 24 bytes); Read Fault History Record Length Exceeds Limit (1 byte <= Data Length <= 64 bytes).
0xDE	0x80	0xB8	0x03	Non-periodic Write Address Invalid (WRREC not run in advance to write read address or address error).
0xDE	0x80	0xB8	0x05	Non-periodic Read Value Failed.
0xDF	0x80	0xB0	0x00	Invalid Data Record Number (Index can only be 100 or 101).
0xDF	0x80	0xB8	0x01	Non-periodic Write Value Function Code Error (Only supports 0x03, 0x10 function codes).
0xDF	0x80	0xB8	0x02	Non-periodic write value data length exceeded (3 bytes <= data length <= 24 bytes); Clear fault history record length exceeded (data length = 1 byte).
0xDF	0x80	0xB8	0x03	Non-periodic write address is invalid.
0xDF	0x80	0xB8	0x04	Non-periodic write set value out of range; Clear fault history record set value illegal (set value can only be 0).

0xDF	0x80	0xB8	0x05	Non-periodic write value failure.
------	------	------	------	-----------------------------------

2.6.3. Retrieve Diagnostic Information

When communication between the module and the inverter is abnormal, diagnostic information will be sent to the PLC, which can be obtained through the DPNRM_DG function block from the diagnostic information sent by the slave station.


1. Add program block

Add a data block in the program block and include the following variables.

Diag									
名称	数据类型	起始值	保持	从 HMI/OPC...	从 H...	在 HMI...	设定值	注释	
1	Static								
2	Channel_CNT	Int	0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
3	Diag_Ret	Int	0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
4	Diag_Record	Array[0..31] of Byte		<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
5	Diag_Busy	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6	Diag_Enable	Bool	false	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

Add the 'Diagnostic error interrupt' organization block in the program block and include the following program in the organization block. This organization block is triggered to execute once each time the PLC receives a diagnostic message from a slave station.





2. Add function block

Add the following program in the Main program block to read diagnostic information when a diagnostic message is received from a slave station.



Diagnostic information is stored in the RECORD parameter, consisting of 9 bytes, defined as follows.


Table 11 RECORD parameter

	Byte 0-Byte 2	Byte 3	Byte 4-Byte 5	Byte 6	Byte 7-Byte 8
Definition	Slave status	Master address	Ident_Number	Device-specific diagnostic length (fixed at 3)	Device-specific diagnostic code, with the same meaning as the periodic fault code (refer to Section 5.1)


2.6.4. Erase fault code

1. Fault code read

Read fault codes using the RDREC function block provided by TIA Portal. The fault codes are the latest 10 fault records from the last power-up to the current read. The record format is as follows:



Example of using the non-periodic read function block: ID: the ID number of the module, INDEX: 101, MLEN: 61, RECORD: the array for storing the read fault records.



Example of parsing the Record array:

Record[0] = 0x02 indicates there are 2 fault records

Record[1] = 0x00 indicates the high byte of the first fault code is 0

Record[2] = 0x33 indicates the first fault code is 0x33, the specific meaning can be found in the table of 5.1 Periodic Fault Codes.

Record[3] = 0x01

Record[4] = 0x02

Record[5] = 0x03

Record[6] = 0x04 Record[3]~ Record[6] indicates the time of the fault occurrence is 0x01020304, which converts to decimal as 16909060, in seconds. Record[1] ~ Record[6] indicates that a fault code 0x33 occurred 16909060 seconds after startup.

Record[7] = 0x00 indicates the high byte of the second fault code is 0.

Record[8] = 0x32 indicates the second fault code is 0x32, the specific meaning can be found in Table 5.1 of Periodic Fault Codes.

Record[9] = 0x00

Record[10] = 0x00

Record[11] = 0x00

Record[12] = 0x05 Record[9]~ Record[12] indicates the time of the fault occurrence is 0x00000005, which converts to decimal as 5, with the unit being seconds

Record[13] = 0x00 Since there are only 2 fault records, all subsequent no-fault data are 0

Record[14] = 0x00


...

Record[60] = 0x00

2. Fault Code Erasure

Use the WRREC function block provided by TIA Portal to erase fault codes, clearing all fault code records (TIA Portal fault records will not be erased).

Example of using the non-cyclic write function block: ID: the ID number of the module, INDEX: 101, MLEN: 1, RECORD: the data setting value for writing is 0.



3. PROFINET Industrial Ethernet Communication

3.1. Product Information

The EMH-PN Communication Expansion Card is a PROFINET fieldbus adapter card that complies with the international standard for PROFINET Ethernet. This card is installed on the CM680 Inverter to enable communication with PROFINET master station devices, making the inverter a PROFINET slave station that accepts control from the master station.

3.1.1. Physical Dimensions

Physical dimensions of the PROFINET module: PCB length 95mm, width 37mm, network port height 13mm, installation hole spacing 30mm, hole diameter 3.5mm.




Figure 11 Physical Dimensions of the EMH-PN Communication Expansion Card

3.1.2. Interface Layout

The hardware layout of the EMH-PN Communication Expansion Card is shown in Figure 12. Pin Header X3 is used for connecting to the inverter and is located on the back of the EMH-PN Communication Expansion Card. The EMH-PN Communication Expansion Card provides two network ports X2 for communication connections. Detailed descriptions of each hardware component are provided in Table 12.




Figure 12 EMH-PN Communication Expansion Card Interface Layout

Table 12 EMH-PN Communication Expansion Card Interface Description

Diagram Name	Hardware Name	Function Description
X1	Socket	UART Interface: Print Operation Information
X2	Ethernet Port	For connecting the PROFINET module to the Profinet network
X3	Board-to-Board Socket	For Connection to Inverter
X4	Screw Terminal	For Firmware Download and Debugging
D1	PROFINET Communication Status Indicator Light	See Table 6 EMH-PN Communication Expansion Card LED Indicator Light Description
D2	Inverter communication status indicator light	
D3	Program run status indicator light	
D4	Hardware power indicator light	

Table 13 EMH-PN Communication Expansion Card LED Indicator Light Description

Diagram Name	Indicator Light	Indicator Light Status		Function Description
D1	PROFINET Communication Status Indicator Light	Red Light	Constantly On	PROFINET Communication Abnormal
			Off	PROFINET Communication Normal
D2	Inverter communication status indicator light	Red Light	Constantly On	Communication timeout with the inverter
			Flashing	Inverter Communication Message Abnormal
			Off	Normal communication with the inverter
D3	Program run status indicator light	Green light	Constantly On	Main program running normally
			Off	Main Program Operation Abnormal
D4	Hardware power indicator light	Green light	Constantly On	Module powered on normally
			Off	Module not powered on

3.2. Installation and Wiring

3.2.1. Installation

The EMH-PN Communication Expansion Card is designed for internal installation in the CM680 Inverter. Before installation, please disconnect the power supply to the inverter and wait for about 10 minutes until the charging indicator light is completely off before proceeding with the installation. After inserting the EMH-PN Communication Expansion Card into the inverter, please secure the corresponding screws to prevent poor contact of the board-to-board signal sockets. The installation diagram is shown in Figure 11.





Figure 13 EMH-PN Communication Expansion Card Installation Diagram


3.2.2. Wiring

Insert an Ethernet cable into the network port of the EMH-PN Communication Expansion Card, then connect it to the PLC. You can connect to either the P1 port or the P2 port according to the network topology in TIA Portal. If the network topology is not specified, any network port P1 or P2 can be connected.

It is recommended to use a Cat 5e shielded network cable.

Common network topology diagrams are as follows:





Star Topology

Figure 14 PROFINET Network Topology

3.3. Communication Description

3.3.1. Key Points of PROFINET Communication

- When using the EMH-PN Communication Expansion Card, the communication decoding method of the CM680 needs to be set. Set the F8-19 register to 0 via the operation panel, and set the F8-07 register to 0 or 1 based on the actual decoding method used.
- When setting the inverter command, the F0-05 register of the CM680 needs to be set to 5.
- When setting the inverter frequency, the F0-06 register of the CM680 needs to be set to 8.
- During non-periodic communication, a new non-periodic communication must only be initiated after the completion of the previous non-periodic read/write. The interval between two non-periodic communications should be no less than 100ms to avoid affecting the response to periodic communication.

3.3.2. Data Transmission Format

The EMH-PN Communication Expansion Card can select different PZD lengths for transmission based on requirements. Users can configure the functions of each PZD in the configuration. The supported functions for each data format are listed in the table below.

Table 14 Supported Functions for Each Data Format

Data Type	Data Length	Supported Functions
Standard Telegram 1	PZD-2/3	2 periodic writes, default 0x6000 control command, 0x6002 frequency setting 3 periodic reads,
Standard Telegram 2	PZD-16/16	16 periodic writes of function parameters Default 0x6000 control command, 0x6002 frequency setting, and other modifiable reserved parameters 0x0830 16 functional parameters read cyclically Fixed 0x2100 errors and warnings, default 0x6100 inverter status, 0x6102 operating frequency read, and other modifiable reserved parameters 0x0830

3.3.3. PZD area data description

Through PZD area data, the master station can modify and read the inverter data in real time, and perform cyclic data exchange. The communication address is configured by the user during configuration. The specific functions are as follows:

- Real-time setting of inverter control command and target frequency
- Real-time reading of inverter current status, operating frequency, and errors and warnings
- Real-time data exchange of functional parameters and monitoring parameters between the inverter and the Profinet master station

PZD process data mainly completes periodic data exchange between the master station and the inverter, see the table below.

Table 15 Exchange Data

Master station sends data to PZD area			
Inverter control command	Inverter target frequency	Real-time modification of inverter function parameters	
PZD1	PZD2	PZD3~PZD16	
Inverter response data PZD area			
Errors and Warnings	Inverter operating status	Inverter operating frequency	Real-time reading of inverter function parameters
PZD1	PZD2	PZD3	PZD4~PZD16

3.3.4. Description of data sent by the master station

Table 16 Description of data sent by the master station to PZD

Master Station Data PZD Description				
PZD1 Control Cmd (Master to Slave)	Inverter Command Word (Command Source Needs to be Set to Communication F0-05 =5)			
	Bit0: CMD_ACT	Bit1: EXT_CMD1	Bit2: EXT_CMD2	Bit3: HALT
	Bit4: LOCK	Bit5: JOG	Bit6: QSTOP	Bit7: SERVO_ON
	Bit8~Bit11: GEAR	Bit12~Bit13: ACC/DEC	Bit14: EN_SW	Bit15: RST
Modifiable by User.				
PZD2 Velocity Cmd (Master to Slave)	Inverter Target Frequency Command Word (Main Frequency Source Needs to be Set to Communication F0-06 =8), Modifiable by User.			
PZD3-PZD16 (Master to Slave)	Default is Address 2096 (Hexadecimal 0x0830), Modifiable by User. Users Can Configure Inverter Function Code Address During Configuration.			

3.3.5. Inverter Response Data Description

Table 17 Inverter Response Data Description

Inverter Response Data Description	
PZD1 fault code (Slave to Master)	Current error and warning information of the inverter, detailed definitions refer to Section 5.1.

PZD2 Status (Slave to Master)	Bit0: ARRIVE Bit4: Reserve Bit8: Ready Modifiable by User.	Bit1: DIR Bit5: JOG Bit9~Bit15: Reserve	Bit2: WARN Bit6: QSTOP	Bit3: ERROR Bit7: SERVO_ON
PZD3 Current Velocity (Slave to Master)	Current operating frequency of the inverter (unit: 0.01Hz). User modifiable.			
PZD4-PZD16 (Slave to Master)	Default is Address 2096 (Hexadecimal 0x0830), Modifiable by User. Users Can Configure Inverter Function Code Address During Configuration.			

3.4. Communication Configuration

Taking the Siemens S7-1500 series PLC as an example, configure the PLC and module to establish Profinet communication.


3.4.1. Configure Configuration

1. Create a project


Double-click to open the TIA Portal software, select 'Create New Project', and the following interface will appear. Choose the save path and project name, then click 'Create'.




After creation, click 'Project View' to enter the main interface. Connect the PLC and PROFINET module to your computer with an Ethernet cable and power them on. In the TIA Portal project tree, under the Online Access menu, click Update Accessible Devices.




List the devices connected to the computer network.




Click on the online and diagnostics of the PLC device to view its model and other information.




Open the 'Function' tree to modify the PLC's IP address, device name, and other configurations.




Click on the online and diagnostics of the module to view module information.




In the function menu, you can modify the device name and IP address. The IP address should be in the same subnet as the PLC's IP address. Click the [Assign IP Address] button to save the modified settings.




On the 'Assign PROFINET Device Name' page, modify the PROFINET device name. After making changes, click the [Assign Name] button to save the modified settings.



In the 'Hardware Catalog' on the right, select the actual PLC model being used; for example, S7-1511. Double-clicking will display the PLC on the configuration page.




Click on the PLC, in the property bar, you can configure information such as the PLC's IP address, which can be modified according to the actual situation.



This completes the establishment of the master station.

2. Install GSDML file

If the GSDML has not been installed, it needs to be installed. In 'Options', select 'Manage General Station Description (GSD) Files'.




Select the path where the GSDML is stored (Note: Do not store the GSDML file in a path with Chinese characters, as this may cause errors), check the GSDML to be installed, and click 'Install'. After installation, select 'Close'.




3. Configure Slave Station


Return to the 'Device and Network' — 'Network View' interface, in the 'Hardware Catalog' on the right, find the CM680 position under Other Field Devices — PROFINET IO — Drives — SUNYE, and double-click to add the module.



Click on 'Unassigned' on the module in the 'Device and Network' interface to assign the master station system to the module.




Select the slave station, and set the IP address and device name in 'Properties' -> 'General' -> 'PROFINET Interface [X1]' -> 'Ethernet Address'. The device name must match the device name set in the online access.



3.4.2. Configure Periodic Communication

1. Configure Module

Select the slave station, switch to the “Device View,” and under “Hardware Catalog” -> “Module,” double-click to select the data length to be configured for the slave station. The configured module will be added in the device view. After adding the module, you can modify the input/output mapping in the PLC by editing the “I Address” and “Q Address”.



2. Configure PZD

Through PZD area data, the master station can real-time modify and read inverter data, and perform periodic data exchange.

PZD process data mainly completes periodic data exchange between the master station and the inverter, the exchanged data is as follows:


Table 18 PZD Process Data

Master station sends data to PZD area			
Inverter Command	Inverter target frequency	Real-time modification of inverter function parameters	
PZD1	PZD2	PZD3~PZD16	
Inverter response data PZD area			
Errors and Warnings	Inverter Status	Inverter operating frequency	Real-time reading of inverter function parameters
PZD1	PZD2	PZD3	PZD4~PZD16

For specific bit definitions, refer to sections 3.4 and 3.5.

PZD3 to PZD12 are user-defined periodic data exchanges, which are set in the hardware configuration.

Select the module added in the previous step, and under 'Properties' -> 'General', choose 'Module Parameters' to set the register address for user-defined periodic data. PZDx(Master to Slave) indicates the address written by the master station to the slave station, and PZDx(Slave to Master) indicates the address read by the master station from the slave station, in decimal format.



After configuration is complete, download the configuration, and the PLC and module will automatically perform periodic data exchange.

3.4.3. Configure Non-periodic Communication


1. Non-periodic Interaction Data Format

Non-periodic interaction uses the slot-subslot-index method for addressing, thereby determining the format of the message data area. To facilitate user operations on consecutive registers of the inverter, the following non-periodic read/write format is defined, with the index set to 100.


The manufacturer has encapsulated two non-periodic read/write function blocks for user reference.

PN_WRITE function block: implements non-periodic writing, ID: represents the moduleID to be written, ADDR: represents the address of the function code to be written,

LEN: represents the number of registers to be written, DATA: array of values to be written into the registers.




PN_READ function block: a function block for non-periodic reading, ID: represents the moduleID to be written, ADDR: represents the address of the function code to be read, MLEN: represents the number of registers to be read, DATA: array to store the values read from the registers.



2. Download Configuration and Ladder Diagram

Save the configured network, set the computer's IP address to the same subnet as the PLC (note that it should not conflict with the IP addresses of the slave stations in the configuration, or you can set the PC to automatically obtain an IP address), compile, click download, select the interface, and then click 'Start Search'. Select the detected PLC, and then click download.



3.5. Fault Information

3.5.1. Periodic Fault Code

In the PZD Area for periodic communication, the high byte of the status word indicates alarm information, allowing users to obtain the latest status through periodic communication. In addition to the diagnostic information of the inverter itself, the communication status between the module and the inverter must also be included to help users identify the cause of errors.

Table 19 Periodic Fault Code

Diagnostic Classification	Status Code
Inverter Body Diagnostic	200 Communication Error (Message Abnormality)
	201 Communication Error (Timeout Abnormality)

Information (Register Address: 0x2100)	202	Address Error
	203	Parameter Exceeds Threshold

3.5.2. Non-periodic Fault Code

When executing non-periodic communication, the STATUS parameter in the function block is used to return the command execution result, with a data type of DWORD (4 bytes). The data format and meaning are already defined in the TIA software. In addition to the standard definition, the following error codes have the following meanings:


Table 20 Non-periodic Fault Code

Function_ Num	Error_ Decode	Error_ Code_1	Error_ Code_2	Meaning
0xDE	0x80	0xB8	0x00	Invalid data record number (index can only be 100 or 101)
0xDE	0x80	0xB8	0x02	Non-periodic read value data length exceeds limit (2<=data length<=24), unit: bytes
0xDE	0x80	0xB8	0x03	Non-periodic write read address is invalid (WRREC has not been run in advance to write the read address or the address is incorrect)
0xDE	0x80	0xB8	0x05	Non-periodic read value failed (communication error between module and inverter)
0xDF	0x80	0xB8	0x00	Invalid data record number (index can only be 100 or 101)
0xDF	0x80	0xB8	0x01	Non-periodic write value function code error (only supports 0x03, 0x10 function codes)
0xDF	0x80	0xB8	0x02	Non-periodic Write Value Data Length Exceeded (3<=Data Length<=24), Unit: Bytes
0xDF	0x80	0xB8	0x03	Non-periodic Write Address Invalid
0xDF	0x80	0xB8	0x04	Non-periodic Write Set Value Out of Range
0xDF	0x80	0xB8	0x05	Non-periodic Write Value Failure (Module and Inverter Communication Error)

3.5.3. Module Information

When communication between the module and the inverter is abnormal, diagnostic information will be sent to the PLC. This can be viewed in the TIA Portal software under PLC's [Online & Diagnostics] — [Diagnostics] — [Diagnostic

Buffer].



3.5.4. Diagnostic Buffer Fault Meaning and Handling

Table 21 Fault Meaning and Handling


Diagnostic Buffer Events	Error Meaning	Correction Handling
Address Error	Periodic Address or Non-periodic Address Error	Periodic Communication PZD Address Contains Invalid Value, Refer to Function Code Table, Correct the Error Address.
Slave status error	Inverter status error	Check the high byte error code definition of PZD1 and take corresponding actions
Communication error	Communication timeout with the inverter	If the error cannot be eliminated, restart the inverter
Parameters error	Periodic parameters error	Modify the periodic parameters to make them comply with the set range

3.5.5. Non-periodic Read or Erase Fault Code


Fault code reading

Read fault codes using the function block Err_History_Read provided by the manufacturer. The fault codes are the latest 10 fault records from the module's power-on to the current read. The record format is as follows:

61个字节的故障历史记录结构



Example of using the non-periodic read function block: ID: the ID number of the module, DATA: the array for storing the read fault records.



Example of parsing the DATA array:

DATA[0] = 0x02 indicates that there are 2 fault records

DATA[1] = 0x00 indicates the high byte of the first fault code is 0

DATA[2] = 0x33 indicates the first fault code is 0x33, the specific meaning can be found in Table 5.1 Periodic Fault Code.

DATA[3] = 0x01

DATA[4] = 0x02

DATA[5] = 0x03

DATA[6] = 0x04 DATA[3]~ DATA[6] indicate the time of the fault occurrence is 0x01020304, which converts to decimal as 16909060, in seconds. DATA[1]~ DATA[6] indicate that the fault code 0x33 occurred 16909060 seconds after startup.

DATA[7] = 0x00 indicates the high byte of the second fault code is 0

DATA[8] = 0x32 indicates the second fault code is 0x32, the specific meaning can be found in the table of periodic fault codes in section 5.1.

DATA[9] = 0x00

DATA[10] = 0x00

DATA[11] = 0x00

DATA[12] = 0x05 DATA[9]~ DATA[12] indicate the time of the fault occurrence is 0x00000005, which converts to decimal as 5, with the unit being seconds

DATA[13] = 0x00 Since there are only 2 fault codes, the subsequent no-fault data are all 0

DATA[14] = 0x00


...

DATA[60] = 0x00

Fault Code Erase

Use the function block Err_History_Clear provided by the manufacturer to erase fault codes, which will clear all fault code records (will not erase the fault records in TIA Portal).

Example of using the non-cyclic write function block: ID: the ID number of the module.




3.6. MRP function description

MRP refers to media redundancy (Media Redundancy Protocol). In PROFINET, this function is implemented through an MRP ring network, with only one MRP ring network allowed in a PROFINET network. Configuration is required during setup when using MRP.

3.6.1. MRP ring network

First, an MRP ring network requires an MRP manager, typically a PLC, while PROFINET modules can only act as MRP clients.


Example of ring topology:



3.6.2. MRP configuration


Step one: configure the MRP manager

An MRP manager must exist in the MRP ring network. The EMH-PN card cannot serve as a manager; typically, a PLC is used as the manager. Select the site to be configured as the manager, and in the interface shown below, select the manager from the 'Media Redundancy Function' drop-down menu.



Step Two: Configure MRP client

Select the slave station, in the interface shown below, in the 'Media Redundancy Function' drop-down select 'Client'. Before configuring the client, the manager must be configured first, otherwise, an error will occur.



Step Three: Download Configuration

After configuring all devices in the MRP ring network, compile and download to the PLC.

Note:

- ◆ All devices in the ring network must be configured as MRP manager or MRP client;
- ◆ MRP configuration does not require setting up a topology diagram; if a topology diagram is needed, it should be set up after completing the MRP configuration;
- ◆ Devices not configured for MRP should not use the ring network, as this can lead to connection failures or repeated station drops.

4. EtherNet/IP Industrial Ethernet Communication

4.1. Product Information

The EMH-EN Communication Expansion Card is an EtherNet/IP fieldbus adapter card that complies with the general EtherNet/IP fieldbus standard. This card is installed on the CM680 Inverter to enable communication with EtherNet/IP master station devices, making the inverter a slave station of EtherNet/IP, accepting control from the master station.

4.1.1. Physical Dimensions

EtherNet/IP Module Physical Dimensions: PCB length 95mm, width 37mm, mounting hole diameter 3.5mm.




Figure 15 Physical Dimensions of the EMH-EN Communication Expansion Card

4.1.2. Interface Layout

The hardware layout of the EMH-EN Communication Expansion Card is shown in Figure 16. Pin Header X3 is used for connecting to the inverter and is located on the back of the EMH-EN Communication Expansion Card. The EMH-EN Communication Expansion Card provides an Ethernet connector for connecting to EtherNet/IP communication. For detailed descriptions of the hardware, refer to Table 22.




Figure 16 EMH-EN Communication Expansion Card Interface Layout

Table 22 EMH-EN Communication Expansion Card Interface Description

Diagram Name	Hardware Name	Function Description
X1	Socket	UART Interface: Print Operation Information
X2	Ethernet Socket	For Module Connection to EtherNet/IP Network
X3	Board-to-Board Socket	For Connection to Inverter
X4	Socket	For Firmware Download and Debugging
D1, D2, D3, D4	LED Indicator Light	Used to indicate the operating status, refer to Table 1.2 for details

LED Indicator Light

Table 23 EMH-EN Communication Expansion Card LED Indicator Light Description

Diagram Name	Indicator Light	Indicator Light Status	Function Description
D1	EtherNet/IP Communication Status Indicator Light	Red Light	Constantly On Indicates No Communication Between the Module and EtherNet/IP Master Station (Check EtherNet/IP Cable Connection and Station Number)
		Off	Indicates Normal Communication Between the Module and EtherNet/IP Master Station
D2	Inverter communication status indicator light	Red Light	Constantly On Communication timeout with the inverter
		Flashing	Inverter Communication Message Abnormal
		Off	Normal communication with the inverter
D3	Program run status indicator light	Green light	Constantly On Main program running normally
		Off	Main program not started properly
D4	Hardware power indicator light	Green light	Constantly On Module powered on normally
		Off	Module not powered on

4.2. Installation and Wiring

4.2.1. Installation

The EMH-EN Communication Expansion Card is designed for internal installation in the CM680 Inverter. Before installation, please disconnect the power supply to the inverter and wait approximately 10 minutes until the inverter charging indicator light is completely off before proceeding with the installation. After inserting the EMH-EN Communication Expansion Card into the inverter, please secure the corresponding screws to prevent poor contact between the board signal sockets. The installation diagram is shown in Figure 14.




Figure 17 EMH-EN Communication Expansion Card Installation Diagram

4.2.2. Wiring

The wiring diagram for the EtherNet/IP bus is shown in Figure 15. Insert a network cable into the network port of the EMH-EN Communication Expansion Card, then connect it directly to the PLC, or indirectly through a switch. It is recommended to use a Cat 5e shielded network cable.




Figure 18 EMH-EN Bus Wiring Diagram

4.3. Communication Description

4.3.1. Key Points for EtherNet/IP Communication

- When using the EMH-EN Communication Expansion Card, you need to set the communication decoding method for the CM680. Set the F8-19 register to 0 via the operation panel, and set the F8-07 register to 0 or 1 based on the actual decoding method used.
- When setting the inverter command, the F0-05 register of the CM680 needs to be set to 5.
- When setting the inverter frequency, the F0-06 register of the CM680 needs to be set to 8.
- The IP address for EtherNet/IP communication of the EMH-EN Communication Expansion Card is set in registers F8-27 to F8-38. The module must be restarted for the settings to take effect.
- During non-periodic communication, a new non-periodic communication must only be initiated after the completion of the previous non-periodic read/write. The interval between two non-periodic communications should be no less than 100ms to avoid affecting the response to periodic communication.

4.3.2. Data Transmission Format

The EMH-EN Communication Expansion Card supports a maximum of 16 register addresses for input (slave to master) and 16 register addresses for output (master to slave) per cycle.

The first input register addresses are fixed as 0x2100 (Errors and Warnings), the second default is 0x6100 (Current Status), and the third default is 0x6102 (Actual Frequency). The remaining 13 registers are 0x0830 (Reserved Address).

The first two output register addresses are default 0x6000 (Control Word) and 0x6002 (Target Frequency). The remaining 14 registers default to 0x0830 (Reserved Address). For detailed information, see the table below.

Table 24 Cycle Data Table

Master Station Sends Data			
OUT ADDR[1]	OUT ADDR[2]	OUT ADDR[3-16]	
0x6000 (Control cmd)	0x6002 (Velocity Cmd)	0x0830 (reserved)	
Slave Station Responds Data			
IN ADDR[1]	IN ADDR[2]	IN ADDR[3]	IN ADDR [4-16]
0x2100 (fault warning code)	0x6100 (Status)	0x6102 (Current Velocity)	0x0830 (reserved)

4.3.3. Description of data sent by the master station

Table 25 Master Station Sent Data PZD Description

Master Station Data PZD Description	
OUT ADDR[1] 0x6000 (Master to Slave)	Inverter Command Word (Command Source Needs to be Set to Communication F0-05 =5) Bit0: CMD_ACT Bit1: EXT_CMD1 Bit2: EXT_CMD2 Bit3: HALT Bit4: LOCK Bit5: JOG Bit6: QSTOP Bit7: SERVO_ON Bit8~Bit11: GEAR Bit12~Bit13: ACC/DEC Bit14: EN_SW Bit15: RST
OUT ADDR[2] 0x6002 (Master to Slave)	Inverter Target Frequency Command Word (Main Frequency Source must be set to Communication F0-06 = 8)
OUT ADDR[3-16] (Master to Slave)	Default is address 2096 (Hexadecimal 0x0830), users can configure the inverter function code address during configuration.

4.3.4. Inverter Response Data Description

Table 26 Inverter Response Data Description

Inverter Response Data Description	
IN ADDR[1] 0x2100 (Slave to Master)	Current error and warning information of the inverter, detailed definitions refer to Section 4.5.
IN ADDR[2] 0x6100 (Slave to Master)	Bit0: ARRIVE Bit1: DIR Bit2: WARN Bit3: ERROR Bit4: Reserve Bit5: JOG Bit6: QSTOP Bit7: SERVO_ON Bit8: Ready Bit9~Bit15: Reserve
IN ADDR[3] 0x6102 (Slave to Master)	Current operating frequency of the inverter (unit: 0.01Hz).
IN ADDR[4-16] (Slave to Master)	Default is address 2096 (Hexadecimal 0x0830), users can configure the inverter function code address during configuration.

4.4. Communication Configuration

Configure the PLC and module to establish EtherNet/IP communication. The configuration process varies for different PLC models; please consult technical support for details.

4.4.1. Configure Configuration

1. Create a project

Open the upper-level computer software, create a new project, and select the device model as AM402-CPU1608TP/TN.

2. Import the EDS file and add the slave station.

Open the network configuration interface, click on the PLC to select the current communication protocol as EtherNet/IP master station, import the EDS file, and import the EIP expansion card's EDS file. Import the device in the network device list.

3. Configure the slave station parameters.

Set the slave station IP address (the slave station IP address can be read and modified via the inverter function code).

Connect the PLC, configure the data, and configure the cyclic input address IN ADDR[1-16] and cyclic output address OUT ADDR[1-16]. The addresses are in decimal, and you need to convert the hexadecimal function codes to decimal.

4. Configure the Master Station

Scan the network to select the master station to be configured.


Assign an IP address to the master station's network port.

Download the project to the PLC.


The upper-level computer can be used to view periodic input and output data.

4.4.2. Configure Non-periodic Communication

Use the Get_Attribute_Single and Set_Attribute_Single function blocks for non-periodic read and write operations.



Non-periodic read and write function code parameter configuration
eClass configuration 100
dwInstance configuration 1
wAttribute configuration the address of the function code to be accessed
pData configuration the address for writing parameters or reading parameters



4.5. Fault Information

4.5.1. Periodic Fault Code

In the periodic communication PZD area, PZD1 sent from the slave station to the master station indicates error and alarm information, allowing users to obtain the latest status through periodic communication. In addition to the diagnostic information of the inverter itself, the communication status between the module and the inverter must also be included, allowing users to obtain the cause of errors. Detailed fault status codes are listed in the table below:

Table 27 Periodic Fault Codes

Diagnostic Classification	Status Code
Inverter Body Diagnostic Information (Register Address: 0x2100)	200 Communication Error (Message Abnormality)
	201 Communication Error (Timeout Abnormality)
	202 Address Error
	203 Parameter Exceeds Threshold

4.5.2. Read and clear fault history

1. Use the Get_Attribute_ALL function block for non-periodic reading of historical fault records, and use the Set_Attribute_ALL function block for non-periodic erasing of historical fault records.

eClass Configuration 101

dwInstance configuration 1


pData configuration the address for writing parameters or reading parameters

PROGRAM PLC_PRG									
类别	名称	地址	数据类型	初值	保持	常量	注释	特性	
8	VAR	EIP_udiDataSize	UDINT	1	<input type="checkbox"/>	<input type="checkbox"/>	del		
9	VAR	EIP_xDone	bool		<input type="checkbox"/>	<input type="checkbox"/>			
10	VAR	EIP_xBusy	bool		<input type="checkbox"/>	<input type="checkbox"/>			
11	VAR	EIP_xError	bool		<input type="checkbox"/>	<input type="checkbox"/>			
12	VAR	EIP_eError	BOOL		<input type="checkbox"/>	<input type="checkbox"/>			
13	VAR	EIP_udiReceivedDataSize	UDINT	1	<input type="checkbox"/>	<input type="checkbox"/>			
14	VAR	EIP_Get	ARRAY[0..60] OF UDINT		<input type="checkbox"/>	<input type="checkbox"/>			
15	VAR	Set_Attribute_Single_test	ENIP.Set_Attribute_Single		<input type="checkbox"/>	<input type="checkbox"/>			
16	VAR	EIP_xExecute1	BOOL		<input type="checkbox"/>	<input type="checkbox"/>			
17	VAR	Set_Attribute_Single_0	ENIP.Set_Attribute_Single		<input type="checkbox"/>	<input type="checkbox"/>			
18	VAR	EIP_Set	ARRAY[0..9] OF UDINT		<input type="checkbox"/>	<input type="checkbox"/>			
19	VAR	Get_Attributes_All_0	ENIP.Get_Attributes_All		<input type="checkbox"/>	<input type="checkbox"/>			
20	VAR	EIP_udiSendDataSize	UDINT		<input type="checkbox"/>	<input type="checkbox"/>			
21	VAR	Set_Attributes_All_0	ENIP.Set_Attributes_All		<input type="checkbox"/>	<input type="checkbox"/>			
22	VAR	EIP_Errcode	word		<input type="checkbox"/>	<input type="checkbox"/>			


```

33  Get_Attributes_All_0(
34      xExecute:= EIP_xExecute,
35      xDone=> EIP_xDone,
36      xBusy=> EIP_xBusy,
37      xError=> EIP_xError,
38      itfEtherNetIPDevice:= SUNYE_OpENer_Device,
39      eClass:= EIP_eClass,
40      dwInstance:= EIP_dwInstance,
41      eError=> EIP_Errcode,
42      pData:= ADDR(EIP_Get),
43      udiDataSize:= SIZEOF(EIP_Get),
44      udiReceivedDataSize=> EIP_udiReceivedDataSize);
45  IF EIP_xDone=TRUE THEN EIP_xExecute :=FALSE;
46  END_IF
47  Set_Attributes_All_0(
48      xExecute:= EIP_xExecute1,
49      xDone=> EIP_xDone,
50      xBusy=> EIP_xBusy,
51      xError=>EIP_xError,
52      itfEtherNetIPDevice:= SUNYE_OpENer_Device,
53      eClass:= EIP_eClass,
54      dwInstance:= EIP_dwInstance,
55      eError=> EIP_Errcode,
56      pData:= ADDR(EIP_Set),
57      udiDataSize:= SIZEOF(EIP_Set));
    
```

2. The structure of the fault history is: 2 bytes for the number of faults, 2 bytes for the fault code, and 4 bytes for the fault occurrence time, with the unit being seconds.



3. Error Code

Table 28 Error Code Meaning

Error Code	Meaning
201	Send Error
202	Communication Timeout
203	Format Error
204	Address Error
205	Data Error
206	Inverter Error
207	Message Error

5. EtherCAT Industrial Ethernet Communication

5.1. Product Information

The EMH-EC Communication Expansion Card is an EtherCat fieldbus adapter card that complies with the international standard for EtherCat fieldbus. This card is installed on the CM680 Inverter to enable communication with EtherCat master station devices, making the inverter a slave station of EtherCat, accepting control from the master station.

5.1.1. Physical Dimensions

Physical dimensions of the EtherCat module: PCB length 95mm, width 37mm, mounting hole diameter 3.5mm.




Figure 19 Physical Dimensions of the EMH-EC Communication Expansion Card

5.1.2. Interface Layout

The hardware layout of the EMH-EC Communication Expansion Card is shown in Figure 20. Pin Header X3 is used for connecting to the inverter and is located on the back of the EMH-EC Communication Expansion Card. The EMH-EC Communication Expansion Card provides 2 network ports, used for connecting the CM680-ECAT card to the master station (or the previous slave station) and the next slave station (if any) for communication.




Figure 20 EMH-EC Communication Expansion Card Interface Layout

Table 29 EMH-EC Communication Expansion Card Interface Description

Diagram Name	Hardware Name	Function Description
X1	Socket	UART Interface: Print operation information, upgrade program
X2	IN/OUT Network Port	Connect to the master station (or the previous slave station) / connect to the next slave station (if any)
X3	Board-to-Board Socket	For Connection to Inverter
X4	Socket	For Firmware Download and Debugging
D1, D2, D3, D4	LED Indicator Light	Used to indicate the operating status, see Table 30 for details

LED Indicator Light

Table 30 EMH-EC Communication Expansion Card LED Indicator Light Description

Diagram Name	Indicator Light	Indicator Light Status	Function Description	
D4	EtherCat Communication Status Indicator Light	Red Light	Constantly On	Indicates that the EtherCat module and EtherCat master station are in init
			Blinking (200ms on-off interval)	indicates that the module is communicating normally with the EtherCat master station
			single flash (200ms on, 1000ms off)	indicates that the EtherCat module and the master station are in PreOp
			flickering (1200ms on-off interval)	indicates that the EtherCat module and the master station are in SafeOp
			double flash (100ms off 100ms on 100ms off 100ms on 800ms off)	indicates that there is a communication error between the EtherCat module and the master station
			Off	indicates that the EtherCat module is communicating normally with the EtherCat master station, in OP
D3	Inverter communication status indicator light	Red Light	Constantly On	the EtherCat module is just powered on or has timed out communication with the inverter
			Off	the EtherCat module and the inverter are communicating normally
			Blinking (200ms on-off interval)	indicates that the EtherCat module and the inverter have received non-periodic error codes
			double flash (100ms off 100ms on 100ms off 100ms on 800ms off)	indicates that the EtherCat module and the inverter have periodic communication errors
D2	Program run status indicator light	Green light	Constantly On	Main program running normally
			Off	Main program not started properly
D1	Hardware power indicator light	Green light	Constantly On	Module powered on normally
			Off	Module not powered on

5.2. Installation and Wiring

5.2.1. Installation

The EMH-EC Communication Expansion Card is designed to be embedded in the CM680 Inverter. Before installation, please disconnect the power supply to the inverter and wait approximately 10 minutes until the inverter's charging indicator light is completely off before proceeding with the installation. After inserting the EMH-EC Communication Expansion Card into the inverter, please secure the corresponding screws to avoid poor contact of the board-to-board signal sockets. The installation diagram is shown in Figure 18.




Figure 21 EMH-EC Communication Expansion Card Installation Diagram

5.2.2. Wiring

The topologies supported by EtherCat include bus, star, tree, and combinations of these topologies, making device connection and wiring very flexible and convenient. The bus connection topology diagram is shown in Figure 19.




Figure 22 EtherCat Bus Wiring Diagram

5.3. Communication Description

5.3.1. Key Points of EtherCat Communication

- When using the EMH-EC Communication Expansion Card, the communication decoding method of the CM680 needs to be set. When using the CANopen standard DS402 specification, set the F8-19 register to 1 via the operation panel. When using manufacturer-defined command codes, set the F8-19 register to 0 via the operation panel. Additionally, check whether the manufacturer-defined command codes are for the 0x6000 or 0x2000 section. When using the 0x6000 section, set the F8-07

register to 1 via the operation panel. When using the 0x2000 section, set the F8-07 register to 0 via the operation panel.

- When setting the inverter command, the F0-05 register of the CM680 needs to be set to 5.
- When setting the inverter frequency, the F0-06 register of the CM680 needs to be set to 8.
- The alias address for EMH-EC Communication Expansion Card EtherCat communication is set in the F8-11 register, and the module must be restarted for the setting to take effect.
- During non-periodic communication, a new non-periodic communication must only be initiated after the completion of the previous non-periodic read/write. The interval between two non-periodic communications should be no less than 100ms to avoid affecting the response to periodic communication.

5.3.2. Periodic Data Read/Write Description

Periodic data exchange is the basic data interaction method of EtherCat. After the master and slave stations establish a normal connection, they will continuously send periodic interaction messages.

Periodic Interaction Data Format:

Periodic interaction sets up 8 PDO areas, 4 of which are RxPDOs, and the other 4 are TxPDOs. There are some default settings for these 8 PDO areas, as shown in the table below:

Table 31 Periodic Interaction Data

PDO	Explanation	Number of PDOs
RxPDO1	Default transmission PDO, used for object dictionary 402, such as 0x6040	Min(16 objects, 32 bytes of data)
RxPDO2	Default transmitted PDO, used for the object dictionary of standard Modbus addresses, such as 0x3060	Min(16 objects, 32 bytes of data)
RxPDO3	Default transmitted PDO, used for the object dictionary of standard Modbus addresses, such as 0x3020	Min(16 objects, 32 bytes of data)
RxPDO4	Non-default freely configurable transmitted PDO	Min(16 objects, 32 bytes of data)
TxPDO1	Default received PDO, used for the object dictionary of 402, such as 0x6041	Min(16 objects, 32 bytes of data)
TxPDO2	Default received PDO, used for the object dictionary of standard Modbus addresses, such as 0x3061	Min(16 objects, 32 bytes of data)
TxPDO3	Default received PDO, used for the object dictionary of standard Modbus addresses, such as 0x3021	Min(16 objects, 32 bytes of data)
TxPDO4	Non-default freely configurable received PDO	Min(16 objects, 32 bytes of data)

The default configured RPDO is 0x1601, and the default configured TPDO is 0x1A01. The first three items of 0x1601 are default mappings, mapping to objects of 402, which are 0x6040, 0x6042, 0x6060, representing control word, set target speed, set mode; the remaining mappings in 0x1601 can be freely configured; The first four items of 0x1A01 are default mappings, with the object at address 402 being 0x603F, 0x6041, 0x6043, 0x6061, representing warning/error, status word, actual operating speed, actual operating mode, respectively. The remaining mappings in 0x1A01 can be freely configured as shown in the table below:

Table 32 Periodic Interaction Data Format 1

Industrial Ethernet Communication

Master Station sends RPDO area (0x1601)				
Default RPDO			Variable RPDO	
Control Word (0x6040)	Set Target Speed (0x6042)	Set Mode (0x6060)	Real-time modification of inverter function parameters	
RPDO1	RPDO2	RPDO3	RPDO4~RPDO16	
Inverter Slave Station replies with TPDO area (0x1A01)				
Default TPDO				Variable TPDO
Warning/Error (0x603F)	Status Word (0x6041)	Actual Running Speed (0x6043)	Actual Running Mode (0x6061)	Real-time reading of inverter function parameters
TPDO1	TPDO2	TPDO3	TPDO4	TPDO5~TPDO16

Another default configuration is 0x1602 and 0x1A02, with a maximum mapping of 16 register addresses. The first two items of 0x1602 are the default RPDO mappings, which are 0x6000, 0x6002, representing control word and set target frequency. The remaining mappings in 0x1602 can be freely configured; The first three items of 0x1A02 are the default mappings, with addresses 0x2100, 0x6100, 0x6102, representing warning/error, status word, and actual frequency. The remaining mappings in 0x1A02 can be freely configured, as shown in the table below:

Table 33 Periodic Interaction Data Format 2

Master Station Sends RPDO Area (0x1602)				
Fixed RPDO			Variable RPDO	
Control Word (0x6000)	Set Target Frequency (0x6002)		Real-time modification of inverter function parameters	
RPDO1	RPDO2	RPDO3~RPDO16		
Inverter Slave Station Responds with TPDO Area (0x1A02)				
Fixed TPDO			Variable TPDO	
Warning/Error (0x2100)	Status Word (0x6100)	Actual Operating Frequency (0x6102)	Real-time reading of inverter function parameters	
TPDO1	TPDO2	TPDO3	TPDO4~TPDO16	

Another default configuration is 0x1603 and 0x1A03, with a maximum mapping of 16 register addresses. The first two items of 0x1603 are the default RPDO mappings, 0x2000, 0x2001, representing control words and set target frequency. The remaining mappings in 0x1603 can be freely configured; The first three items of 0x1A03 are default mappings, with mapping addresses 0x2100, 0x2101, 0x2103, representing warning/error, status word, actual frequency. The remaining mappings in 0x1A03 can be freely configured, as shown in the table below:

Table 34 Periodic Data Exchange Format 3

Master Station sends RPDO area (0x1603)				
Fixed RPDO			Variable RPDO	
Control Word (0x2000)	Set Target Frequency (0x2001)		Real-time modification of inverter function parameters	
RPDO1	RPDO2	RPDO3~RPDO16		
Inverter Slave Station replies with TPDO area (0x1A03)				

Fixed TPDO			Variable TPDO
Warning/Error (0x2100)	Status Word (0x2101)	Actual Operating Frequency (0x2103)	Real-time reading of inverter function parameters
TPDO1	TPDO2	TPDO3	TPDO4~TPDO16

Additionally, 0x1604 and 0x1A04 have no default mapping configurations and are available for user configuration.

5.3.3. Non-periodic Data Read/Write Instructions

Non-periodic data read/write is used for obtaining or writing non-real-time data, interacting only when necessary.

There are two methods of non-periodic interaction, one is to access non-periodic data through the COE-Online method, and the other is to complete non-periodic interaction through custom object dictionary indexes.

5.3.3.1. Non-periodic COE-Online Acquisition

COE-Online accesses data from all object dictionaries listed in the ESI file in sequence, including data reading and writing. Since the content of the object dictionary is written based on the function codes of the inverter, the sub-indexes under an index are not necessarily continuous. Therefore, using the Complete access method to access data can cause data misalignment, so COE-Online only supports non-Complete access methods to access sub-index objects one by one. As shown in the figure below, the parameters of the inverter are read non-periodically in sequence through the COE-Online method.

Industrial Ethernet Communication

General EtherCAT DC Process Data Plc Startup **CoE - Online** Online


Update List Auto Update Single Update Show Offline Data

Advanced...

Add to Startup... Module OD (AoE Port):

Index	Name	Flags	Value	Unit
+ 1C12:0	RxPDO assign	RW	> 1 <	
+ 1C13:0	TxPDO assign	RW	> 1 <	
+ 1C32:0	SM output parameter	RO	> 32 <	
+ 1C33:0	SM input parameter	RO	> 32 <	
- 3000:0	Basic Function Para		> 19 <	
3000:01	[F0-00]Identity Code	RO	0x10D1 (4305)	
3000:02	[F0-01]Duty Selection	RW	0x0001 (1)	
3000:03	[F0-02]Rated Current	RO	0x0514 (1300)	
3000:04	[F0-03]Control Method	RW	0x0000 (0)	
3000:05	[F0-04]Velocity Mode	RW	0x0000 (0)	
3000:06	[F0-05]Source of OPER	RW	0x0005 (5)	
3000:07	[F0-06]Source of FREQ	RW	0x0008 (8)	
3000:08	[F0-07]AUX FREQ Source	RW	0x0000 (0)	
3000:09	[F0-08]AUX FREQ FUN SEL	RW	0x0000 (0)	
3000:...	[F0-09]Fwd/Rev Forbid	RW	0x0000 (0)	
3000:...	[F0-10]Upper Bound FREQ	RW	0xE9FC (59900)	
3000:...	[F0-11]Lower Bound FREQ	RW	0x0000 (0)	
3000:...	[F0-12]ACC/DEC TimeUnit	RW	0x0000 (0)	
3000:0E	[F0-13]1st ACC Time	RW	0x03E8 (1000)	
3000:0F	[F0-14]1st DEC Time	RW	0x03E8 (1000)	
3000:10	[F0-15]Carry Frequency	RW	0x0006 (6)	
3000:11	[F0-16]Derating Method	RW	0x0000 (0)	
3000:12	[F0-17]High Speed Mode	RW	0x0000 (0)	
3000:13	[F0-18]Parameter Reset	RW	0x0000 (0)	

The following figure shows the non-periodic modification of a sub-index value through the COE-Online method to change the inverter parameter value.



5.3.3.2. Non-periodic acquisition of custom object dictionary

1. Non-periodic interaction data format

Non-periodic interaction is accomplished using specific object dictionary indexes to determine the format of the message data area. To facilitate user operations on continuous registers of the inverter, the following non-periodic read/write formats are defined. Non-periodic reads use a combination of object dictionary indexes 0x5300 and 0x5301, while non-periodic writes use the object dictionary index 0x5600.

1) Non-periodic write value (0x5600)

When executing a non-periodic write value command, the data area must include the starting address of the register, length, and value. The data area has a fixed length of 16, and unused data areas are automatically filled with 0. The specific format is as follows:

Table 35 Non-periodic Write Value Format

	Register Address	Register Length	Data
Data Length	2 Byte	2 Byte	Valid Data Area (Register Length * 2) Byte + Invalid Data Area
Example	0x0400	0x10	0x0001 0002 0003 0004 0005...

The figure below is an example of an actual object dictionary:

Index	Name	Flags	Value
5600:0	Noncyclic data write	RW	> 18 <
5600:01	DataWriteAddr	RW	1024
5600:02	DataWriteNum	RW	16
5600:03	DataWrite1	RW	1
5600:04	DataWrite2	RW	2
5600:05	DataWrite3	RW	3
5600:06	DataWrite4	RW	4
5600:07	DataWrite5	RW	5
5600:08	DataWrite6	RW	6
5600:09	DataWrite7	RW	7
5600:...	DataWrite8	RW	8
5600:...	DataWrite9	RW	9
5600:...	DataWrite10	RW	10
5600:...	DataWrite11	RW	11
5600:0E	DataWrite12	RW	12
5600:0F	DataWrite13	RW	13
5600:10	DataWrite14	RW	14
5600:11	DataWrite15	RW	15
5600:12	DataWrite16	RW	16

The total length of the non-periodic write value data area is at least 2 Byte and a maximum of 32 Byte.

2) Non-periodic Read Value (0x5300 + 0x5301)

In the non-periodic read value request message, the register address and number to be read must first be written to the index 0x5301, as shown in the figure, the address written is 0x0400, reading 16 registers, so it is 0x00 10 04 00, the data read is stored in the index 0x5300, as shown in the figure, the fixed maximum number of non-periodic reads is 16 registers, the values read are sequentially filled into the sub-indices of 0x5300, for example, the 16 register values read this time are 1~16, if there are unused data areas, they are automatically filled with 0.

The specific format of the 0x5301 index is as follows

Table 36 0x5301 Index Format

	Number of Registers	Register Address
Data Length	2 Byte	2 Byte
Example	0x0400	0x0010

After sending a non-periodic read value command, the read value is filled into the 0x5300 index, and unused index values are automatically filled with 0. The data area format is as follows:

Table 37 Data Area Format

	Data
Data Length	(Register Length * 2) Byte
Example	0x0001 0002 0003 0004 0005...

3) Execution Result

If an exception occurs during non-periodic interaction, an error code will be returned. Refer to Table 12 for specific error code definitions.

Table 38 EMH-EC Communication Expansion Card SDO Transmission Error Codes

Error Code	Meaning
0x05030000	No change in the toggle bit during segmented transfer
0x05040000	SDO transfer timeout
0x05040001	Invalid or unknown command code
0x05040005	Memory overflow
0x06010000	Operation on a certain object is not supported
0x06010001	Read a write-only data object
0x06010002	Write a read-only data object
0x06010003	The entry cannot be written because sub-index 0 is not 0
0x06010004	The object cannot be accessed via complete access
0x06020000	The data object does not exist in the data dictionary
0x06040041	The data object cannot be mapped to PDO
0x06040042	The number and length of data objects to be mapped exceed the PDO data length
0x06040043	Parameter Incompatible
0x06040047	Device Internal Incompatibility
0x06060000	Hardware Error
0x06070010	Parameter Length Mismatch
0x06070012	Parameter Length Too Long
0x06070013	Parameter Length Too Short
0x06090011	Subindex Does Not Exist
0x06090030	Write Operation: Data Value Out of Range
0x06090031	Data Value Too Large
0x06090032	The data value to be written is too small
0x06090033	0xF030 and 0xF050 do not match
0x06090036	The maximum value is less than the minimum value
0x08000000	General Error
0x08000020	Data cannot be read or written
0x08000021	Due to local control reasons, the data cannot be transmitted or saved to the application
0x08000022	Data cannot be read or written in the current state
0x08000023	The object cannot be found in the current object dictionary

5.4. Communication Configuration

The following describes the simple configuration and usage process of the CM680-ECAT card using Beckhoff's TwinCAT3 master station as an example.



Note: For the network card, an Intel chip-based 100 Mbps Ethernet card must be selected. Network cards from other brands may pose a risk of not supporting EtherCAT operation.


5.4.1. Configure Configuration

1. Install TwinCAT3


2. Copy the CM680 EtherCat configuration file (CM680H_PLUS_IO_V1.5.xml) to the TwinCAT installation directory, TwinCAT3 directory: TwinCAT\3.1\config\IO\EtherCAT.

3. Open TwinCAT


Create a new project, click on 'Create New Project', and the following interface will appear. You can search for TwinCAT templates, select the 'TwinCAT XAE Project (XML format)' template, and click Next.



The following interface will appear. After filling in the project name and save location, click Create.




After creation, you need to install the TwinCAT network card driver.



Open the menu 'Show Real Time Ethernet Compatible Devices...', and the following dialog box will appear. In the 'Incompatible devices' section, select the local site and click 'Install'. After installation, the installed network card will appear in the 'Installed and ready to use devices' section as shown in the figure below.




After the driver installation is complete, connect the device and search for it by right-clicking on Device and selecting Scan, as shown in the figure below.



Click OK.




Select the Ethernet that has just installed the Ethercat driver and click OK.




Click Yes.



Click OK.




Click Yes. At this point, the device search is complete, as shown in the figure below.




5.4.2. Configure Periodic Communication

1. Configure TPDO

Select the slave station, then select the 'Process Data' item on the right, and choose SM3, which is Inputs. You will see four TPDO options: 0x1A01, 0x1A02, 0x1A03, and 0x1A04. Among these, 0x1A01 is the default configuration for the standard DS402 protocol object dictionary, 0x1A02 and 0x1A03 are default configurations for custom function codes, and 0x1A04 has no default mapping object configuration and is available for user configuration. Users can select one of the four TPDOs according to their needs, and check the box before the selected TPDO. The currently selected TPDO is 0x1A01, as shown in the following steps.




For the default TPDO 0x1A01, the default mapping objects configured are 4, as shown in the following figure: 0x3021:01 Warn/Error, 0x6041:00 Status Word, 0x6043:00 Velocity Demand, 0x6061:00 Mode of Operation Display. Since 0x6061:00 Mode of Operation Display is 1 byte, to align the bytes, an unused empty object needs to be added, as shown in Figure 1.




For the default configuration of 0x1A01, it is not recommended that users modify the first (4+1) configured objects. However, users can add new objects after these, as shown in the following figure, by right-clicking and adding a new item after the last object.

Industrial Ethernet Communication



Then, a list of all object dictionaries will pop up, as shown in the figure below, from which you can select the object dictionary you want to add.




For the object dictionary you want to add that does not appear in the popped-up object dictionary list, you can manually input it, as shown in the figure below, in the red box marked, input the object dictionary you want to add, and also pay attention to the mapping relationship between the object dictionary and the inverter function code as follows:

Object Dictionary Index = 0x3000 + Function Code Group Number;

Object Dictionary Sub-index = Function Code Group Internal Offset in Hexadecimal + 1;

Therefore, as shown in the figure below, the object dictionary 0x3009+2 manually added represents the inverter function code 0x0901.



In addition, note that 1) if the length of the object dictionary being added is less than 2 bytes, it must be padded with dummy object dictionaries to achieve 2-byte alignment; 2) the maximum number of object dictionaries that can be added under a single PDO is $\min(16, \text{the number of objects corresponding to 32 bytes of object dictionary length})$.

For the default TPDO 0x1A02, the default mapping objects configured are 3, as shown in the figure below, which are 0x3021:01 Warn/Error, 0x3061:01 Inverter State, 0x3061:03 Output Frq.

General EtherCAT DC Process Data Plc Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	Mbx...	
1	128	MbxIn	
2	4	Outp...	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A01	8.0	Converter Inputs_1			0
0x1A02	6.0	Converter Inputs_2		3	0
0x1A03	6.0	Converter Inputs_3			0
0x1A04	0.0	Converter Inputs_4			0
0x1601	6.0	Converter Outputs_1			0
0x1602	4.0	Converter Outputs_2		2	0
0x1603	4.0	Converter Outputs_3			0
0x1604	0.0	Converter Outputs_4			0

PDO Assignment (0x1C12):

0x1601
 0x1602
 0x1603
 0x1604

Download

PDO Assignment
 PDO Configuration

Predefined PDO Assignment: (none)

Load PDO info from device

Sync Unit Assignment...

PDO Content (0x1A02):

Index	Size	Offs	Name	Type	Default (h...
0x3021:01	2.0	0.0	Warn/Error	UINT	
0x3061:01	2.0	2.0	Inverter State	UINT	
0x3061:03	2.0	4.0	Output Frq	INT	
	6.0				

For the default configuration of 0x1A02, it is not recommended that users modify the first three configured objects, but users can add desired objects after these. The method of adding objects is the same as the configuration for 0x1A01. Additionally, if customers want to use 0x1A04 without default configuration, the method of adding objects is also the same.

For the default TPDO 0x1A03, there are 3 default mapped objects, as shown in the figure below, which are 0x3021:01 Warn/Error, 0x3021:02 Inverter State, 0x3021:04 Output Frq.

General EtherCAT DC Process Data Plc Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	Mbx...	
1	128	MbxIn	
2	4	Outp...	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A01	8.0	Converter Inputs_1		0	
0x1A02	6.0	Converter Inputs_2		3	0
0x1A03	6.0	Converter Inputs_3		0	
0x1A04	0.0	Converter Inputs_4		0	
0x1601	6.0	Converter Outputs_1		0	
0x1602	4.0	Converter Outputs_2		2	0
0x1603	4.0	Converter Outputs_3		0	
0x1604	0.0	Converter Outputs_4		0	

PDO Assignment (0x1C12):

0x1601
 0x1602
 0x1603
 0x1604

PDO Content (0x1A03):

Index	Size	Offs	Name	Type	Default (h...
0x3021:01	2.0	0.0	Warn/Error	UINT	
0x3021:02	2.0	2.0	Inverter State	UINT	
0x3021:04	2.0	4.0	Output Frq	INT	
		6.0			

Download

PDO Assignment
 PDO Configuration

Predefined PDO Assignment: (none)


Load PDO info from device

Sync Unit Assignment...


For the default configuration of 0x1A03, it is not recommended that users modify the first 3 configured objects, but users can add objects they wish to include after these, using the same method as configuring 0x1A01.

2. Configure RPDO

Select the slave station, then select the 'Process Data' item on the right, and select SM2, i.e., Outputs. You can see four TPDO options: 0x1601, 0x1602, 0x1603, and 0x1604. Among them, 0x1601 is the standard DS402 protocol object dictionary configured by the manufacturer by default, 0x1602 is the custom function code configured by the manufacturer by default, and 0x1603 and 0x1604 do not have default mapped objects and are available for user configuration. Users can choose one of the four RPDOs according to their needs, and check the box before the selected RPDO. The default selected is 0x1601, as shown in the following steps.



For the default RPDO 0x1601, there are 3 default mapped objects configured, as shown in the following figure: 0x6040:00 Control Word, 0x6042:00 v1 target velocity, 0x6060:00 Mode of Operation. Since 0x6060:00 Mode of Operation is 1 byte, to align the bytes, an unused empty object needs to be added, as shown in 1 in the following figure.



For the default configuration 0x1601, it is not recommended that users modify the first (3+1) configured objects, but users can add objects they wish to include after these, using the same method as configuring 0x1A01.

For the default RPDO 0x1602 configuration, there are 2 default mapped objects, as shown in the figure below, which are 0x3060:01 Control Word, 0x3060:03 vl target velocity.

General EtherCAT DC Process Data Plc Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	Mbx...	
1	128	MbxIn	
2	4	Outp...	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A01	8.0	Converter Inputs_1			0
0x1A02	6.0	Converter Inputs_2		3	0
0x1A03	6.0	Converter Inputs_3			0
0x1A04	0.0	Converter Inputs_4			0
0x1601	6.0	Converter Outputs_1			0
0x1602	4.0	Converter Outputs_2		2	0
0x1603	4.0	Converter Outputs_3			0
0x1604	0.0	Converter Outputs_4			0

PDO Assignment (0x1C12):

0x1601
 0x1602
 0x1603
 0x1604

PDO Content (0x1602):

Index	Size	Offs	Name	Type	Default (h...
0x3060:01	2.0	0.0	Control Word	UINT	
0x3060:03	2.0	2.0	vl target velocity	INT	
4.0					

Download

PDO Assignment
 PDO Configuration

Predefined PDO Assignment: (none)

Load PDO info from device

Sync Unit Assignment...

For the 0x1602 with default configuration, it is not recommended that users modify the first 2 configured objects, but users can add objects they wish to increase after these, using the same method as configuring 0x1A01. Additionally, if customers want to use 0x1604 without default configuration, the method of adding objects is the same.

For the default RPDO 0x1603 configuration, there are 2 default mapped objects, as shown in the figure below, which are 0x3020:01 Operation Command, 0x3020:02 Speed Setpoint Command.

General EtherCAT DC Process Data Plc Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	Mbx...	
1	128	MbxIn	
2	4	Outp...	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags	SM	SU
0x1A01	8.0	Converter Inputs_1			0
0x1A02	6.0	Converter Inputs_2		3	0
0x1A03	6.0	Converter Inputs_3			0
0x1A04	0.0	Converter Inputs_4			0
0x1601	6.0	Converter Outputs_1			0
0x1602	4.0	Converter Outputs_2		2	0
0x1603	4.0	Converter Outputs_3			0
0x1604	0.0	Converter Outputs_4			0

PDO Assignment (0x1C12):

0x1601
 0x1602
 0x1603
 0x1604

PDO Content (0x1603):

Index	Size	Offs	Name	Type	Default (h...
0x3020:01	2.0	0.0	Operation Command	UINT	
0x3020:02	2.0	2.0	Speed Setpoint Command	INT	

Download

PDO Assignment
 PDO Configuration

Predefined PDO Assignment: (none)

Load PDO info from device


Sync Unit Assignment...

For the 0x1603 with default configuration, it is not recommended that users modify the first 2 configured objects, but users can add objects they wish to increase after these, using the same method as configuring 0x1A01.

5.4.3. Configure Non-periodic Communication

5.4.3.1. Non-periodic COE-Online Acquisition

After the user activates to PreOP and higher states, they can monitor data in real-time through the COE-Online SDO data list, and can also modify SDO data by double-clicking the object dictionary.



5.4.3.2. Custom object dictionary for non-cyclic read/write

1. Non-cyclic write

Section 5.3.3.2 has already introduced using a custom object dictionary to operate multiple consecutive registers of the inverter, and now the specific configuration steps are demonstrated.


For the convenience of users, two non-cyclic read/write function blocks that can be used directly are encapsulated: the read function block is Noncyclic_Read2, and the write function block is Noncyclic_Write2. Both function blocks include the capability to obtain SDO transmission error codes. Each execution of a non-cyclic read or write will retrieve an SDO transmission error code, and if there is no error, the error code will return 0. The example code after calling these two function blocks is shown in the figure below, where the red box indicates the instantiation and invocation of the function blocks.

表达式	类型	值	准备值
Noncyclic_Read_5300	Noncyclic_Read2		
WriteBuffer_5301	ARRAY [1..2] OF UINT		
ReadBuffer_5300	ARRAY [1..30] OF U...		
Abortcode_5300	ST_ECAbortCode		
result_5300	INT	0	
i	INT	0	
a	INT	0	
bExecute_Write_5600	BOOL	FALSE	
WriteBuffer_5600	ARRAY [1..30] OF U...		
Abortcode_5600	ST_ECAbortCode		
result_5600	INT	0	
Noncyclic_write_5600	Noncyclic_Write2		

```

1  IF bExecute_Write_5600 FALSE THEN
2      result_5600 := 0;
3      Noncyclic_Write_5600
4      bExecute_Write_5600 := TRUE;
5      WriteBuffer_5600 := WriteBuffer_5600;
6      NetID := '10.143.255.146.2.1';
7      SlaveAddr := 1001;
8      Abortcode_5600 := Abortcode_5600;
9      Result := result_5600;
10 IF (result_5600 <> 0) THEN
11     bExecute_Write_5600 := FALSE;
12 IF (result_5600 <> 0) THEN
13     times_5300_ERROR := times_5300_ERROR + 1;
14 END_IF
15 times := times + 1;
16 END_IF
17 END_IF
18
19 IF bExecute_Write_5301 FALSE THEN
20     result_5300 := 0;
21     Noncyclic_Read_5300
22     bExecute_Write_5301 := TRUE;
23     WriteBuffer_5301 := WriteBuffer_5301;
24     NetID := '10.143.255.146.2.1';
25     SlaveAddr := 1001;
26     ReadBuffer_5300 := ReadBuffer_5300;
27     Abortcode_5300 := Abortcode_5300;
28     Result := result_5300;
29 IF (result_5300 <> 0) THEN
30     bExecute_Write_5301 := FALSE;
31     a := 1;
32 END_IF
    
```

The variables bExecute_Write_5600 and bExecute_Write_5301 indicate whether to perform a non-periodic read. The values of sNetID and nSlaveAddr in the function block need to be entered according to the actual operation of EtherCAT, as shown in the figure below:



The array WriteBuffer_5600 is used to write the starting address of the Modbus to be written, the number of registers to be written, and the values of each register to be written, as shown in the figure below.

表达式	类型	值	准备值	地址
ReadBuffer_5300	ARRAY [1..30] OF U...			
Abortcode_5300	ST_EcAbortCode			
result_5300	INT	16#0000		
i	INT	16#0000		
a	INT	16#0000		
bExecute_Write_5600	BOOL	FALSE		
WriteBuffer_5600	ARRAY [1..30] OF U...			
WriteBuffer_5600[1]	UINT	16#0000	16#0432	
WriteBuffer_5600[2]	UINT	16#0000	16#000A	
WriteBuffer_5600[3]	UINT	16#0000	16#0001	
WriteBuffer_5600[4]	UINT	16#0000	16#0002	
WriteBuffer_5600[5]	UINT	16#0000	16#0003	
WriteBuffer_5600[6]	UINT	16#0000	16#0004	
WriteBuffer_5600[7]	UINT	16#0000	16#0005	
WriteBuffer_5600[8]	UINT	16#0000	16#0006	
WriteBuffer_5600[9]	UINT	16#0000	16#0007	
WriteBuffer_5600[10]	UINT	16#0000	16#0008	
WriteBuffer_5600[11]	UINT	16#0000	16#0009	
WriteBuffer_5600[12]	UINT	16#0000	16#000A	
WriteBuffer_5600[13]	UINT	16#0000		
WriteBuffer_5600[14]	UINT	16#0000		
WriteBuffer_5600[15]	UINT	16#0000		
WriteBuffer_5600[16]	UINT	16#0000		
WriteBuffer_5600[17]	UINT	16#0000		

```


1 IF bExecute_Write_5600 FALSE THEN
2   result_5600[16#0000] := 0;
3   Noncyclic_write_5600(
4     bExecute_Write_5600 FALSE := TRUE,
5     WriteBuffer_5600 := WriteBuffer_5600,
6     NetID := '10.143.255.146.2.1',
7     SlaveAddr[16#0000] := 1001,
8     Abortcode_5600 := Abortcode_5600,
9     Result[16#0000] => result_5600[16#0000]);
10 IF (result_5600[16#0000] <> 0) THEN
11   bExecute_Write_5600 FALSE := FALSE;
12   IF (result_5600[16#0000] = 2) THEN
13     times_5300_ERROR[16#0000] := times_5300_ERROR[16#0000] + 1;
14   END_IF
15   times[16#0000] := times[16#0000] + 1;;
16 END_IF
17 END_IF

```

When the values are ready, they are written, and bExecute_Write_5600 is set to True, which will execute a non-periodic write operation. You can check the values returned by the function block's

Industrial Ethernet Communication

Result and Abortcode_5600, as well as the error list below, to determine if the aperiodic write was successful. If Result equals 1 and nAbortCode under Abortcode_5600 equals 0, then the aperiodic write was successful. If Result equals 2, it indicates that an SDO transfer error code has been obtained. The specific error can be seen in the nAbortCode value under Abortcode_5600, which is explained in Table 3.1. If Result equals 3, it indicates an ADS error. For detailed information on ADS errors, refer to the TwinCAT 3 help documentation.



In the example, result_5600 equals 1, nAbortCode equals 0, and there are no errors listed below, so the aperiodic write was successful.

库管理器 | Noncyclic_Write2 [Online] | TwinCAT Project7 | Main_3 [Online] -> X

TwinCAT_Project7.Untitled1.Main_3

表达式	类型	值	准备值	地址
Abortcode_5600	ST_EcAbortCode			
sNetId	T_AmsNetIdArr			
nPort	UINT	16#0000		
nAbortCode	UDINT	16#00000000		
result_5600	INT	16#0001		
Noncyclic_write_5600	Noncyclic_Write2			
times	INT	16#0006		
times_5300_ERROR	INT	16#0000		

```

4   bExecute_Write_5600 TRUE := TRUE,
5   WriteBuffer_5600 := WriteBuffer_5600,
6   NetID '10.143.255' := '10.143.255.146.6.1' ,
7   SlaveAddr '16#03E9' := 1001,
8   Abortcode_5600 => Abortcode_5600 ,
9   Result '16#0001' => result_5600 '16#0001' );
10  IF (result_5600 '16#0001' < 0 ) THEN
11    bExecute_Write_5600 FALSE := FALSE;
12    IF (result_5600 '16#0001' = 2) THEN
13      times_5300_ERROR '16#0000' := times_5300_ERROR '16#0000' + 1;
14    END IF
15    times '16#0006' := times '16#0006' + 1;;
16  END IF
17  END IF
18
19  IF bExecute_Write_5301 FALSE THEN

```


错误列表

整个解决方案 | 错误 0 | 警告 0 | 消息 14 | Clear | 生成 + IntelliSense


代码	说明
i	2023/5/19 14:52:34 218 ms 'TwinCAT System' (10000): Starting COM Server TcEventLogger !
i	2023/5/19 14:52:33 148 ms 'License Server' (30): license validation status is Valid(3)
i	2023/5/19 14:52:32 926 ms 'TwinCAT System' (10000): TcRTIME Server started: TcRTIME.
i	2023/5/19 14:52:32 918 ms 'TwinCAT System' (10000): TcPlc30 Server started: TcPlc30.
i	2023/5/19 14:52:32 909 ms 'TwinCAT System' (10000): TcNc Server started: TcNc.
i	2023/5/19 14:52:32 899 ms 'TwinCAT System' (10000): TcIo Server started: TcIo.
i	2023/5/19 14:52:32 893 ms 'TwinCAT System' (10000): TcIoECat Server started: TcIoECat.
i	2023/5/19 14:52:32 886 ms 'TwinCAT System' (10000): TcRtsObjects Server started: TcRtsObjects.

We can also switch to COE-Online to confirm that the values starting from register 0x0432 have indeed been changed to the values 1~10 that we previously wrote.

Industrial Ethernet Communication



If a non-cyclical write operation is performed on a read-only register address 0x0001, it will return an SDO transfer error code and an Emergency error. As shown in the following two figures.



Noncyclic_Write2 [Online] 库管理器 6 TwinCAT Project7 Main_3 [Online] ×

TwinCAT_Project7\Inititled1.Main_3

表达式	类型	值	准备值	地址	注释
result_5300	INT	16#0000			
i	INT	16#0000			
a	INT	16#0000			
bExecute_Write_5600	BOOL	FALSE			
WriteBuffer_5600	ARRAY [1..30] OF U...				
Abortcode_5600	ST_EcAbortCode				
sNetId	T_AmsNetIdArr				AmsNetId of the send... f the aborted comm...
nPort	UDINT	16#015E			Port of the sender of the aborted command
nAbortCode	UDINT	16#05040001			Abort code
result_5600	INT	16#0002			
Noncyclic_write_5600	Noncyclic_Write2				

```

1 IF bExecute_Write_5600|FALSE THEN
2   result_5600[16#0002]:=0;
3   Noncyclic_write_5600(
4     bExecute_Write_5600|TRUE|=- TRUE,
5     WriteBuffer_5600:= WriteBuffer_5600,
6     NetId["10.143.255.0"]:= '10.143.255.146.6.1' ,
7     SlaveAddr[16#00E9]:= 1001,
8     Abortcode_5600:=Abortcode_5600 ,
9     Result[16#0002]:=result_5600[16#0002] );
10  IF (result_5600[16#0002] < 0) THEN
11    bExecute_Write_5600|FALSE|=-FALSE;
12    IF (result_5600[16#0002] = 2) THEN
13      times_5300_ERROR[16#0001]:=times_5300_ERROR[16#0001]+1;
14    END IF
15    times[16#0008]:=times[16#0008]+1;;
16  END IF
17 END_IF
18
19 IF bExecute_Write_5300|FALSE THEN
20   result_5300[16#0002]:=0;

```

错误列表

整个解决方案 错误 2 警告 0 消息 0 Clear 生成 + IntelliSense

代码	说明
2023/5/19 16:13:49 349 ms	"Drive 1 (CM680H_PLUS)" (1001): CoE ("InitDown" 0x5600:01) - SDO Abort ("Client/server command specifier not valid or unknown.", 0x05040001).
2023/5/19 16:13:49 343 ms	"Drive 1 (CM680H_PLUS)" (1001): CoE - Emergency (Hex: #f00, cc: '00 00 00 00 00).

2. Non-cyclical Read

Write the parameters for non-cyclical read into the WriteBuffer_5301 array, as shown in the figure below. The register address to be read is the previously non-cyclical written address 0x0432, and the number of registers to be read is 10. Then set bExecute_Write_5301 to TRUE, write the value, and a non-cyclical read will be executed once.

The screenshot displays the TwinCAT Project7 IDE interface. At the top, the 'Main_3 [Online]' window is active, showing a table of variables. Below the table, the ladder logic for the 'bExecute_Write_5301' variable is visible, including a conditional execution block.

表达式	类型	值	准备值	地址	注释
OutputCounter	INT	16#0000		%Q*	
InputCounter	INT	16#0000		%I*	
bExecute_Write_5301	BOOL	FALSE	TRUE		
Noncyclic_Read_5300	Noncyclic_Read2				
WriteBuffer_5301	ARRAY [1..2] OF UINT				
WriteBuffer_5301[1]	UINT	16#0000	16#0432		读的寄存器地址
WriteBuffer_5301[2]	UINT	16#0000	16#000A		读的寄存器个数
ReadBuffer_5300	ARRAY [1..30] OF U...				
Abortcode_5300	ST_EcAbortCode				
result_5300	INT	16#0000			
i	INT	16#0000			

```

13 times_5300_ERROR[16#0001]:=times_5300_ERROR[16#0001]+1;
14 END_IF
15 times[16#0008]:=times[16#0008]+1;
16 END_IF
17 END_IF_
18
19
20 IF bExecute_Write_5301 FALSE<TRUE> THEN
21 result_5300[16#0000]:=0;
22 Noncyclic_Read_5300(
23 bExecute_Write_5301 FALSE:=TRUE ,
24 WriteBuffer_5301:= WriteBuffer_5301,
25 NetID[ ] :='10.143.255.146.6.1' ,
26 SlaveAddr[16#0000]:= 1001,
27 ReadBuffer_5300=>ReadBuffer_5300 ,
28 Abortcode_5300=>Abortcode_5300 ,
29 Result[16#0000 ]> result_5300[16#0000] );
30 IF (result_5300[16#0000]<>0 ) THEN
31 bExecute_Write_5301 FALSE<TRUE> :=FALSE;
32 a[16#0000]:=1;
33 END_IF

```

错误列表

整个解决方案 错误 0 警告 0 消息 0 Clear 生成 + IntelliSense

If the non-cyclical read is executed successfully, the values of the 10 read register addresses will be saved in the ReadBuffer_5300 array, as shown in the figure below.

表达式	类型	值	准备值	地址	注释
OutputCounter	INT	16#0000		%Q*	
InputCounter	INT	16#0000		%I*	
bExecute_Write_5301	BOOL	FALSE			
Noncyclic_Read_5300	Noncyclic_Read2				
WriteBuffer_5301	ARRAY [1..2] OF UINT				
ReadBuffer_5300	ARRAY [1..30] OF U...				
ReadBuffer_5300[1]	UINT	16#0001			
ReadBuffer_5300[2]	UINT	16#0002			
ReadBuffer_5300[3]	UINT	16#0003			
ReadBuffer_5300[4]	UINT	16#0004			
ReadBuffer_5300[5]	UINT	16#0005			
ReadBuffer_5300[6]	UINT	16#0006			
ReadBuffer_5300[7]	UINT	16#0007			
ReadBuffer_5300[8]	UINT	16#0008			
ReadBuffer_5300[9]	UINT	16#0009			
ReadBuffer_5300[10]	UINT	16#000A			
ReadBuffer_5300[11]	UINT	16#0000			
ReadBuffer_5300[12]	UINT	16#0000			
ReadBuffer_5300[13]	UINT	16#0000			
ReadBuffer_5300[14]	UINT	16#0000			

→ 读到的10个寄存器的值

```

15      times[16#0008] := times[16#0008] + 1;
16      END_IF
17      END_IF
18
19      IP bExecute_Write_5301[FALSE] THEN
20          result_5300[16#0001] := 0;
21          Noncyclic_Read_5300(
22              bExecute_Write_5301[TRUE] := TRUE,
23              WriteBuffer_5301 := WriteBuffer_5301,
24              NetID '10.143.255' := '10.143.255.146.6.1',
25              SlaveAddr: 16#03E9 := 1001,
26              ReadBuffer_5300 => ReadBuffer_5300,
27              Abortcode_5300 => Abortcode_5300,
28              Result[16#0001] => result_5300[16#0001]);
29          IF (result_5300[16#0001] <> 0) THEN
30              bExecute_Write_5301[FALSE] := FALSE;
    
```

The method to determine whether the non-cyclical read is executed successfully is the same as the method for non-cyclical write, by checking the values of the Result and Abortcode_5300 returned by the function block, as well as the error list below. If there is an SDO transfer error code for non-periodic reads, the method to check it is the same as for non-periodic writes.

3. Explanation of Encapsulated Non-periodic Read/Write Function Blocks

To allow users to perform non-periodic read/write operations without needing to understand Modbus messages, the manufacturer has encapsulated two non-periodic read/write function blocks for user reference.

Noncyclic_Write2 function block: implements non-periodic writing, where bExecute_Write_5600: can always be set to TRUE, WriteBuffer_5600: configures the register, including the register address, number of registers, and the value to be written to the register, NetID: the AMS route of the EtherCAT master station, SlaveAddr: the station address of the slave station, Abortcode_5600: the SDO transfer error code returned, Result: the execution result (1 indicates successful execution, 2 indicates an SDO transfer error code was obtained, 3 indicates an ADS error occurred while obtaining the SDO transfer code).

```
IF bExecute_Write_5600 THEN
    result_5600:=0;
    Noncyclic_write_5600(
        bExecute_Write_5600:= TRUE,
        WriteBuffer_5600:= WriteBuffer_5600,
        NetID:='10.143.255.146.6.1' ,
        SlaveAddr:= 1001,
        Abortcode_5600=>Abortcode_5600 ,
        Result=>result_5600 );
    IF (result_5600 <>0 ) THEN
        bExecute_Write_5600:=FALSE;
        IF (result_5600 =2) THEN
            times_5300_ERROR:=times_5300_ERROR+1;
        END_IF
        times:=times+1;;
    END_IF
END_IF
```

Noncyclic_Read2 function block: a function block that implements non-periodic reading, where bExecute_Write_5301: can always be set to TRUE, WriteBuffer_5301: configures the register, including the register address and number of registers, NetID: the AMS route of the EtherCAT master station, SlaveAddr: the station address of the slave station, ReadBuffer_5300: the value read from the register, Abortcode_5300: the SDO transfer error code returned, Result: the execution result (1 indicates successful execution, 2 indicates an SDO transfer error code was obtained, 3 indicates an ADS error occurred while obtaining the SDO transfer code).

```

IF bExecute_Write_5301 THEN
    result_5300:=0;
    Noncyclic_Read_5300(
        bExecute_Write_5301:=TRUE ,
        WriteBuffer_5301:= WriteBuffer_5301,
        NetID:='10.143.255.146.6.1' ,
        SlaveAddr:= 1001,
        ReadBuffer_5300=>ReadBuffer_5300 ,
        Abortcode_5300=>Abortcode_5300 ,
        Result=> result_5300);
    IF (result_5300<>0 ) THEN
        bExecute_Write_5301:=FALSE;
        a:=1;
    END_IF
END_IF
    
```

5.5. Fault Information

5.5.1. Periodic Fault Code

In the periodic communication PDO area, PDO1 sent from the slave station to the master station indicates error and alarm information. Users can obtain the latest status through periodic communication. In addition to the diagnostic information of the inverter itself, the communication status between the module and the inverter must also be included, allowing users to obtain the cause of errors. Detailed fault status codes are listed in the table below:

Table 39 Periodic Fault Codes

Diagnostic Classification	Status Code
Inverter Body Diagnostic Information (Register Address: 0x2100)	200 Communication Error (Message Abnormality)
	201 Communication Error (Timeout Abnormality)
	202 Address Error
	203 Parameter Exceeds Threshold
	204 Incorrect Slave Station Number
	205 Incorrect Periodic Data Value
	206 SPI Transmission Without Memory
	207 SPI Transmission Error
	208 Periodic Communication Error

5.5.2. Non-periodic Fault Code

When executing non-periodic communication, the error code of SDO transmission will be returned. For details on error codes, see Table 38.

5.5.3. Retrieve Diagnostic Information

When communication between the module and the inverter is abnormal, diagnostic information is sent to the PLC. Diagnostic information can be obtained through object dictionary 0x10F3. As shown in the figure below, up to the latest 14 diagnostic messages can be displayed.

Industrial Ethernet Communication

Index	Name	Flags	Value	Unit
10F1:0	Error Settings	RO	> 2 <	
10F3:0	Diagnosis history	RO	> 7 <	
10F3:01	Maximum messages	RO	0x0E (14)	
10F3:02	Newest message	RO	0x07 (7)	
10F3:03	Newest acknowledged message	RW	0x00 (0)	
10F3:04	New messages available	RO	FALSE	
10F3:05	Flags	RW	0x0000 (0)	
10F3:06	Diagnosis message 1	RO	00 E8 00 FF 02 00 CC 00 D7 CE 09 1D 75 30 3D 0A	
10F3:07	Diagnosis message 2	RO	00 E8 00 FF 02 00 CC 00 E7 2C 14 74 7D 30 3D 0A	
10F3:08	Diagnosis message 3	RO	---	
10F3:09	Diagnosis message 4	RO	---	
10F3:0A	Diagnosis message 5	RO	---	
10F3:0B	Diagnosis message 6	RO	---	
10F3:0C	Diagnosis message 7	RO	---	
10F3:0D	Diagnosis message 8	RO	---	
10F3:0E	Diagnosis message 9	RO	---	
10F3:0F	Diagnosis message 10	RO	---	
10F3:10	Diagnosis message 11	RO	---	
10F3:11	Diagnosis message 12	RO	---	
10F3:12	Diagnosis message 13	RO	---	
10F3:13	Diagnosis message 14	RO	---	
1601:0	RxPDO1-Map	RW	> 4 <	

The format of the diagnostic information is as follows:

Table 40 Diagnostic Information Format

Example	00	E8	10	FF	02	00	00	00	00	00	00	00	00	00	00
Purpose	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)	(L) (H)
	(Fixed Value)	Error code	(Fixed Value)	Text ID	(Fixed Value)	Text ID	(Fixed Value)	Text ID	(Fixed Value)	Text ID	(Fixed Value)	Text ID	(Fixed Value)	Text ID	(Fixed Value)
	Diag code			Flags	Text ID	Time stamp									

Diag code ... diagnostic code for identifying information

Error code diagnostic code as defined.

Flags ... value is fixed at 0002h.

Text ID ... Returns the Text ID defined for each error code.

Set the upper 8-bit as the main alarm number and the lower 8-bit as the auxiliary alarm number.

Time stamp ... The time when the error occurred.

5.5.4. Non-periodic Read or Erase Fault Code

1. Fault code read

Read the 0x10F3 object using the FB_EcCoESdoReadEx function block provided by Twincat3 or obtain it directly via COE-Online. The following figure shows the consistent results obtained through FB_EcCoESdoReadEx and COE-Online. Note that complete access is not supported for operations on 0x10F3.

Industrial Ethernet Communication

Diag_10F3 Noncyclic_Read2 [Online] Diag_Message TwinCAT Project7 Main_3 [Online] ↗ ✕

TwinCAT_Project7.Untitled1.Main_3

表达式	类型	值	准备值	地址
Diag_Message_Instance[0]	Diag_Message			
Data	ARRAY [0..15] OF B...			
Data[0]	BYTE	16#00		
Data[1]	BYTE	16#E8		
Data[2]	BYTE	16#00		
Data[3]	BYTE	16#FF		
Data[4]	BYTE	16#02		
Data[5]	BYTE	16#00		
Data[6]	BYTE	16#CC		
Data[7]	BYTE	16#00		
Data[8]	BYTE	16#7B		
Data[9]	BYTE	16#B1		
Data[10]	BYTE	16#5F		
Data[11]	BYTE	16#F8		
Data[12]	BYTE	16#24		
Data[13]	BYTE	16#37		
Data[14]	BYTE	16#3D		
Data[15]	BYTE	16#0A		

```

30     bExecute_Write_S301 FALSE := FALSE;
31     a[16#0001] := 1;
32     END_IF
33     END_IF
34
35     SdoRead_10F3 (
36       sNetId [10.143.255] := '10.143.255.146.6.1',
37       nSlaveAddr [16#03E9] := 1001,
38       nSubIndex [16#06] := 16#06,
39       nIndex [16#10F3] := 16#10F3,
40       pDstBuf [16#FFFF938BC6522CB8] := ADR(Diag_Message10F3_Instance.Diag_Message_Instance),
41       cbBufLen [16#000000E0] := SIZEOF(Diag_Message10F3_Instance.Diag_Message_Instance),
42       bExecute :=,
43       tTimeout [T#10s] := T#10S,
44       bCompleteAccess FALSE := FALSE,
45       bBusy =>,
46       bError =>,
47       nErrId => ); RETURN
    
```

10F3:0	Diagnosis history	RO	> 6 <
10F3:01	Maximum messages	RO	0x0E (14)
10F3:02	Newest message	RO	0x06 (6)
10F3:03	Newest acknowledged message	RW	0x00 (0)
10F3:04	New messages available	RO	FALSE
10F3:05	Flags	RW	0x0000 (0)
10F3:06	Diagnosis message 1	RO	00 E8 00 FF 02 00 CC 00 7B B1 5F F8 24 37 3D 0A
10F3:07	Diagnosis message 2	RO	---
10F3:08	Diagnosis message 3	RO	---
10F3:09	Diagnosis message 4	RO	---
10F3:0A	Diagnosis message 5	RO	---
10F3:0B	Diagnosis message 6	RO	---
10F3:0C	Diagnosis message 7	RO	---
10F3:0D	Diagnosis message 8	RO	---

2. Fault Code Erasure

Write 0 to sub-index 3 of 0x10F3 using the FB_EcCoESdoWriteEx function block provided by TwinCAT3 to clear all diagnostic information, as shown in the following figure:


表达式	类型	值	准备值	地址
times	INT	16#0009		
times_5300_ERROR	INT	16#0002		
Diag_Message10F3_Instance	Diag_10F3			
u16SubIndex0	UINT	16#0000		
u8MaximumMessages	USINT	16#00		
u8NewestMessage	USINT	16#00		
u8NewestAckMessage	USINT	16#00		
u8NewMessage	USINT	16#00		
Flags	UINT	16#0000		
Diag_Message_Instance	ARRAY [0..13] OF D...			
SdoRead_10F3	FB_EcCoESdoReadEx			
SdoWrite_10F3	FB_EcCoESdoWriteEx			
sNetId	T_AmsNetId	'10.143.255.146...		
nSlaveAddr	UINT	16#03E9		
nSubIndex	BYTE	16#03		
nIndex	WORD	16#10F3		
pSrcBuf	PVOID	16#FFFF938BC6...		
cbBufLen	UDINT	16#00000001		
bExecute	BOOL	TRUE		
tTimeout	TIME	T#10s		
bCompleteAccess	BOOL	FALSE		
bBusy	BOOL	FALSE		

```

48
49
50 SdoWrite_10F3(
51   sNetId[10.143.255.146] := '10.143.255.146.6.1',
52   nSlaveAddr[16#03E9] := 1001,
53   nSubIndex[16#03] := 16#03,
54   nIndex[16#10F3] := 16#10F3,
55   pSrcBuf[16#FFFF938BC6522CB4] := ADR(Diag_Message10F3_Instance.u8NewestAckMessage[16#00]),
56   cbBufLen[16#00000001] := SIZEOF(Diag_Message10F3_Instance.u8NewestAckMessage[16#00]),
57   bExecute :=,
58   tTimeout[T#10s] := T#10S, //T#30s
59   bCompleteAccess[FALSE] := FALSE,
60   bBusy :=,
61   nErrId := );RETURN

```

Or write 0 directly to sub-index 3 of 0x10F3 via COE-Online, as shown in the following figure:



6. CANopen Communication

6.1. Product Information

The EMH-OP Communication Expansion Card is a CANopen fieldbus adapter card that complies with the CiA standard. This card is installed on the CM680 Inverter to enable communication with CANopen master station devices, making the inverter a slave node of the CANopen network, accepting control from the master station.

6.1.1. Physical Dimensions

Physical dimensions of the CANopen module: PCB length 95mm, width 37mm, mounting hole diameter 3.5mm.




Figure 23 Physical Dimensions of the EMH-OP Communication Expansion Card

6.1.2. Interface Layout

The hardware layout of the EMH-OP Communication Expansion Card is shown in Figure 24. Connector X2 is used for connecting to the inverter and is located on the back of the EMH-OP Communication Expansion Card. The EMH-OP Communication Expansion Card provides spring-type terminal blocks for communication connections. Detailed descriptions of each hardware component are provided in Table 41.




Figure 24 EMH-OP Communication Expansion Card Interface Layout

Table 41 EMH-OP Communication Expansion Card Interface Description

Diagram Name	Hardware Name	Function Description
X1	CAN Socket	For module connection to the CANopen network, refer to Figure 1.3 for details
X2	Board-to-Board Socket	For connection to the inverter (located on the back of the board)
D1	LED Indicator Light	For indicating power status, refer to Table 1.2 for details
S1	Termination Resistor Setting	For setting the CAN bus termination resistor, refer to Table 1.6 for details

1. CANopen communication interface

The EMH-OP communication expansion card uses a spring-type terminal block X1 to connect to the CAN bus, and the shield is twisted together and connected to the PE (J703-1) of the main control board. If conditions permit, the shield of the communication line can also be connected to the cabinet metalwork. The pin signal definitions are shown in the figure below:




Figure 25 EMH-OP Communication Expansion Card CAN Communication Interface Description

2. LED Indicator Light

Table 42 EMH-OP Communication Expansion Card LED Indicator Light Description

Diagram Name	Indicator Light	Indicator Light Status		Function Description
D1	Hardware power indicator light	Green light	Constantly On	Module powered on normally
			Off	Module not powered on

3. Terminal Impedance

The DIP switch S1 on the EMH-OP Communication Expansion Card is a 2-position DIP switch used to configure the CAN bus terminal resistor. It is recommended to set the terminal resistor at both ends of the network topology. Switching to “ON” represents “1”, and switching down represents “0”. For detailed information, see Table 15.

Table 43 EMH-OP Communication Expansion Card Terminal Resistor Settings

DIP Switch Number		Terminal Impedance Setting
1	2	
0	0	Do Not Use Terminal Resistor
1	1	Use Terminal Resistor

6.2. Installation and Wiring

6.2.1. Installation

The EMH-OP Communication Expansion Card is designed to be embedded in the CM680 Inverter. Before installation, please disconnect the power supply to the inverter, wait for about 10 minutes until the charging indicator light is completely off before proceeding with the installation. After inserting the EMH-OP Communication Expansion Card into the inverter, please secure the corresponding screws to prevent poor contact of the board-to-board signal sockets. The installation diagram is shown in Figure 2.1.




Figure 26 Schematic Diagram of EMH-OP Communication Expansion Card Installation

6.2.2. Wiring

The wiring diagram for the CAN bus is shown in Figure 2.2. The CAN bus is recommended to use shielded twisted pair cables. Terminal matching resistors should be connected at both ends of the CAN bus. Adjust the DIP switches according to the indications on the terminal blocks. Failure to connect or insufficiently connect the terminal resistors can affect communication quality and cause unstable communication.




Figure 27 CAN Bus Wiring Diagram

6.3. Communication Description

6.3.1. Key Points of CANopen Communication

The CANopen communication sub-protocol CiA 301 (DS 301) includes periodic communication and event-triggered communication.

The CANopen device sub-protocol defines direct access to inverter parameters and key process data.

The inverter's CANopen interface supports the CiA 402 (DS 402, inverter and motion control sub-protocol) specification and the inverter manufacturer's custom specifications.

The maximum transmission distance of CANopen is limited by the transmission speed; the higher the speed, the shorter the communication distance.

Theoretically, up to 127 communication nodes can be connected in a CAN network; in practice, the number of nodes is limited by the transmission capability of the CAN transceiver.

Unless otherwise specified, the inverter is defined as a slave node (Server) in the CAN network.

Table 44 CANopen Protocol

Application layer	CANopen Application layer	
Presentation layer		
Session layer		
Transport layer		
Network layer		
Data link layer		CAN2.0A/B
Physical layer		ISO 11898

Table 45 CANopen Parameter Settings

Name	Description	Default Value
F8-07 Communication Decoding Method	Select manufacturer-defined protocol, 0 indicates custom protocol one, 1 indicates custom protocol two	1
F8-14 CANopen Node Address	Set node address, each device in the same network must have a unique node address. 0: Disable CANopen Slave Station, 1~127: Slave Node Address Number, a single CAN network supports up to 127 slave nodes.	0
F8-15 CAN Bus Communication Speed	User selects CANopen communication speed, all devices in the same network must use the same communication speed.	0
F8-18 CANopen Warning Record	Displays inverter CANopen warning information	Read-Only
F8-19 CiA402 Protocol Selection	Used to select CiA 402 protocol and manufacturer-defined protocol for CANopen index parsing. 0: Inverter manufacturer-defined protocol, 1: CiA 402 protocol	1

Name	Description	Default Value
F8-07 Communication Decoding Method	Select manufacturer-defined protocol, 0 indicates custom protocol one, 1 indicates custom protocol two	1
F8-20 CANopen communication status	Display inverter CANopen node status	Read-Only
F8-21 CiA402 operation status	Display inverter motor operation status	Read-Only
F8-22 CANopen index reset	CANopen index data reset command	0xFFFF

6.3.2. CANopen communication protocol

The CANopen communication protocol includes NMT (Network Management Object), SYNC (Synchronous Object), SDO (Service Data Object), PDO (Process Data Object, including transmitting TPDO, Tx PDO and receiving RPDO, Rx PDO, transmission and reception are referenced to the CANopen node itself), and EMCY (Emergency Object).

Table 46 Communication Protocol

Communication Object	Function Code (binary)	COB-ID(hex)
NMT	0000	00
SYNC	0001	80
EMCY	0001	81 ... FF
TPDO1	0011	181 ... 1FF
RPDO1	0100	201 ... 27F
TPDO2	0101	281 ... 2FF
RPDO2	0110	301 ... 37F
TPDO3	0111	381 ... 3FF
RPDO3	1000	401 ... 47F

Communication Object	Function Code (binary)	COB-ID(hex)
TPDO4	1001	481 ... 4FF
RPDO4	1010	501 ... 57F
TSDO	1011	581 ... 5FF
RSDO	1100	601 ... 67F

COB-ID encoding format is as follows:

Table 47 COB-ID (CAN Object ID, 11 or 29 bits)

Function Code				Node ID						
10	9	8	7	6	5	4	3	2	1	0

6.3.2.1. NMT

NMT follows the Master/Slave protocol model, where the NMT host can unconditionally control the state transitions of the slave. NMT management involves six states from the start of power-up of a CANopen node, including Initialization, Application Layer Reset, Communication Reset, Pre-Operational Mode, Operational Mode, and Stop Mode. The data field of a CAN communication frame corresponding to an NMT message is 2 bytes long, and the ID field is 0.

Table 48 NMT Message

ID field	Data field (Byte 0)	Data field (Byte 1)
0	NMT CMD	Node ID

If the Node ID is 0, it indicates that all NMT broadcast frames will be responded to by all slave stations. The NMT CMD list is as follows:

Table 49 NMT CMD

NMT CMD	Meaning
01h	Start Remote Node
02h	Stop Remote Node
80h	Enter Pre-Operation Mode
81h	Node Reset
82h	Communication Reset

The list of node statuses is as follows:

Table 50 Node Status

Node Status Word	Meaning
00h	Boot-up
04h	Stop State
05h	Operation Mode
FFh	Pre-Operation Mode

The CANopen state machine is as follows:




Figure 28 CANopen State Machine

The effective working states of each communication protocol object are shown in the following table:

Table 51 Effective Working States

	Initialization	Pre-Operation Mode	Operation Mode	Stop State
PDO	\	\	Active	\
SDO	\	Active	Active	\
SYNC	\	Active	Active	\
EMCY	\	Active	Active	\
NMT	\	Active	Active	Active
Boot-up	Active	\	\	\

6.3.2.2. SDO

SDO follows the Client/Server protocol model, used for transmitting data with less stringent timing requirements (parameter setting), data length 0~4 bytes. Common SDO protocol is Fast SDO (SDO command byte bit1 set to 1 indicates Fast SDO), meaning all data is transmitted during initialization (initial SDO upload/download). If the transmission length exceeds 4 bytes, Fast SDO cannot be used, and standard SDO must be used for segmented transmission. The object dictionary is a group object of the CANopen node, each node has its own object dictionary, which contains multiple parameters, describing the supported parameter attributes and values. SDO accesses the device object dictionary through index and sub-index, each object has a single index value, and a single index can have multiple sub-index values. The SDO data frame format is as follows:

Table 52 SDO Data Frame Format

SDO Data Frame Analysis

data byte num	Comment
byte0	SDO CMD
byte1	SDO Index Low Byte
byte2	SDO Index High Byte
byte3	SDO sub-index
byte4	SDO data low word low byte
byte5	SDO data low word high byte
byte6	SDO data high word low byte
byte7	SDO data high word high byte

These 4 bytes are invalid when the SDO client queries the server status

SDO CMD Analysis

bit num	Comment
bit0	size
bit1	expedited
bit2	Number of unused bytes in SDO
bit3	
bit4	\
bit5	cmd 1: init download (send parameters) 2: init upload (status query) 3: stop SDO transfer
bit6	
bit7	

6.3.2.3. PDO

PDO follows the Producer/Consumer protocol model, where each network node can receive information from the transmitting node and can also determine whether to process the received information, used for transmitting time-critical process data (reference values, control commands, status information, etc.), which can be transmitted one-to-one or one-to-many. PDO transmission can be initiated by an internal timer (asynchronous communication), upon receiving a synchronization frame (synchronous communication), and through remote requests. The CAN interface supports up to 8 PDOs (including 4 TPDOs and 4 RPDOs), with only TPDO1 and RPDO1 enabled by default. PDO mapping can be used to transmit multiple application objects in a single PDO frame. PDO object mapping can only be modified when the node is in pre-operational mode.

- PDO mapping format CANopen object mapping value is in hexadecimal encoding, PDO mapping data format is as follows:

Table 53 PDO Mapping Data Format

Type	MSB		LSB
UINT32	31 16	15 8	7 0
Description	Index (e.g., 6040h)	Sub-Index (e.g., 02h)	Object bit length (e.g., 10h corresponds to 16 bits, 08h corresponds to 8 bits)

Note:

1. PDO mapping sub-index starts from 1.
2. If the PDO mapping input value is 0, the mapping of the current sub-index and all subsequent sub-indices will be ignored.

PDO transmission type settings and transmission methods correspond as follows:

Table 54 PDO Transmission Type

Transmission type setting value	Cyclic	Non-cyclic	Synchronous	Asynchronous	Remote Request
0	\	Active	Active	\	\
1~240	Active	\	Active	\	\
252	\	\	Active	\	Active
253	\	\	\	Active	Active
255	\	\	\	Active	\

A transmission type value of 0 indicates that two PDOs transmit synchronous non-cyclic information (currently unsupported). A transmission type value of 1~240 indicates the number of SYNCs between two PDO transmissions. A transmission type value of 252 indicates that data is updated immediately after receiving SYNC (currently unsupported). A transmission type value of 253

indicates that data is updated immediately after receiving RTR (currently unsupported). A transmission type value of 255 indicates asynchronous non-cyclic transmission.

- **PDO Mapping Configuration via SDO** This section provides an example of configuring a slave station's PDO mapping via the CANopen master station's SDO. Other PDO configurations should refer to this example. The slave station's PDO configuration is as follows:

1. Node ID = 1;
2. RPDO1: 6040h Control Word, 6042h Target Speed;
3. TPDO1 : 6041h Status Word, 6043h Actual Target Speed;
4. TPDO1 is sent to the master station with a 100ms cycle.

In the pre-operational mode of the CANopen slave node, the object configuration is as shown in the following table: RPDO1 mapping configuration steps:

Table 55 RPDO1 Mapping Configuration Steps

Step	Index (hex)	sub-Index (hex)	Name	Write Value (hex)	Description
1	1400	01	RPDO1 Parameter: COB-ID	80000201	Disable RPDO1
2	1400	02	RPDO1 Parameter: Transmission Type	FF	Transmission Type 255
3	1600	00	RPDO1 Mapping: Number of Entries	0	Write 0 before Mapping Configuration
4	1600	01	RPDO1 Mapping: Mapped Object 1	60400010	6040h Control Word, Subindex 00, Data Length 16bits
5	1600	02	RPDO1 Mapping: Mapped Object 2	60420010	6042h Target Speed, Subindex 00, Data Length 16bits
6	1600	00	RPDO1 Mapping: Number of Entries	2	Map 2 Objects
7	1400	01	RPDO1 Parameter: COB-ID	201	Enable RPDO1

TPDO1 Mapping Configuration Steps:

Table 56 TPDO1 Mapping Configuration Steps

Step	Index (hex)	sub-Index (hex)	Name	Write Value (hex)	Description
------	-------------	-----------------	------	-------------------	-------------

Step	Index (hex)	sub-Index (hex)	Name	Write Value (hex)	Description
1	1800	01	TPDO1 Parameter: COB-ID	80000183	Disable TPDO1
2	1800	02	TPDO1 Parameter: Transmission Type	FF	Transmission Type 255
3	1800	05	TPDO1 Parameter: Event Timer	64	100ms
4	1A00	00	TPDO1 Mapping: Number of Entries	0	Write 0 before Mapping Configuration
5	1A00	01	TPDO1 Mapping: Mapped Object 1	60410010	6041h Status Word, Subindex 00, Data Length 16bits
6	1A00	02	TPDO1 Mapping: Mapped Object 2	60430010	6043h Actual Target Speed, Subindex 00, Data Length 16bits
7	1A00	00	TPDO1 Mapping: Number of Entries	2	Map 2 Objects
8	1800	01	TPDO1 Parameter: COB-ID	183	Enable TPDO1

6.3.2.4. EMCY

The emergency object is triggered when an internal fault occurs in the CANopen device, informing the CANopen master station of the fault code via an emergency frame. The emergency frame is a diagnostic message and does not affect CANopen communication. Refer to 6. CANopen Fault Codes for CANopen fault codes.

6.3.3. Communication Sub-Protocol

The communication sub-protocol specifies the meaning of parameters, control words, status words, and variable values (reference values and actual values) transmitted and received via the CAN bus. The inverter supports two sub-protocols:

- CiA 402. The inverter internally converts the CiA 402 protocol. The inverter defaults to using the CiA 402 protocol.
- Inverter manufacturer protocol. There are two protocols: Protocol One (F8-07=0) can only operate the inverter in speed mode, while Protocol Two (F8-07=1) can operate the inverter in both speed and torque modes. The selection of the sub-protocol standard can be achieved through parameter F8-19.




Figure 29 Communication Sub-Protocol Selection Diagram

The CANopen control index definitions supported by the inverter are as follows:

Table 57 CANopen Control Index

CANopen Protocol Standard Selection	Speed Mode		Torque Mode		Operation Control	
	index-subindex	Meaning	index-subindex	Meaning	index-subindex	Meaning
CiA402	0x6042-0x00	Target Speed (rpm)	0x6071-0x00	Target Torque (%)	0x6040-0x00	Operation Command
	\	\	0x6072-0x00	Maximum Torque Limit (%)	0x605A-0x00	Fast Shutdown Handling Method
	\	\	\	\	0x605C-0x00	Prohibited Operation Handling Method
Midea Protocol One	0x2020-0x02	Target Frequency (Hz)	\	\	0x2020-0x01	Operation Command
Midea Protocol Two	0x2060-0x03	Target Frequency (Hz)	0x2060-0x07	Target Torque (%)	0x2060-0x01	Operation Command
	0x2060-0x04	Torque Limit (%)	0x2060-0x08	Frequency Limit (%)	\	\

General Indexes Do Not Require Sub-Protocol Selection, All Can Be Used, Relevant Indexes Are as Follows:

- Read-Only (RO) Attribute Indexes.
- Parameter Group Read-Write Indexes (0x2010-0x01 ~ 0x201F-0x64, 0x2070-0x01 ~ 0x20B0-0x64)
- Acceleration/Deceleration Time Setting Indexes (0x604F-0x00, 0x6050-0x00)

CM680 Inverter Communication Manual
CANopen Communication

bits	15~9	8	7	6~4	3	2	1	0
Meaning	Reserved	halt	Fault Reset	Normal Operation	Operational Enable	Fast Shutdown	Enable Voltage	Running

Note: To start the motor, first send 0xxxx110 (06h) to enter the Ready to Switch ON state under no error conditions, then send 0xxxx111 (07h) to enter the Switch ON state, and the motor will start rotating.

Table 59 Status Word (Index 6041h)

bits	15~14	13~12	11	10	9	8	7	6	5	4	3	2	1	0
Meaning	Reserved	Normal Operation	Amplitude Limiting Action	Target Value Reached	Remote Control	Reserved	Warning	Disable Operation	Fast Shutdown	Voltage Enable	Fault	Operation Enable	Running	Operation Preparation Complete

CANopen Object Dictionary

Table 60 Standard Object Dictionary (Object Dictionary)

Index	Object
0000h	Reserved
0001h ~ 025Fh	Data Types (Data types)
0260h ~ 0FFFh	Reserved
1000h ~ 1FFFh	通讯对象子协议区(Communication profile area)
2000h ~ 5FFFh	制造商特定子协议区(Manufacturer-specific profile area)
6000h ~ 9FFFh	标准化设备子协议区(Standardized profile area)
A000h ~ AFFFh	Standardized Network variable area, compliant with IEC61131-3
B000h ~ BFFFh	Standardized System variable area for routing gateways

Index	Object
C000h ~ FFFFh	Reserved

Table 61Communication profile area

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
1000	0	Device type	unsigned 32	RO	Device Type Description
1001	0	Fault Register	unsigned 8	RO	Describe fault type, refer to the fault register description table below for details
1005	0	Synchronous Message COB-ID	unsigned 32	RW	Synchronous message COB-ID for synchronous transmission
1006	0	Synchronous Communication Cycle Period	unsigned 32	RW	Set synchronous communication cycle period (us)
100C	0	Guard Time	unsigned 16	RW	Guard time (ms) * Lifetime factor = Node guard protocol lifetime
100D	0	Lifetime Factor	unsigned 8	RW	Guard time (ms) * Lifetime factor = Node guard protocol lifetime
1010	1	Save Parameters	unsigned 32	RW	Write SDO value 0x65766173 (“evas”) to save all parameters
	2				Write SDO value 0x65766173 (“evas”) to save communication parameters (index 0x1000~0x1FFF)
1011	1	Restore default parameters	unsigned 32	RW	Write SDO value 0x64616F6C (“daol”) to restore all parameters to default values
	2				Write SDO value 0x64616F6C (“daol”)

CM680 Inverter Communication Manual
CANopen Communication

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
					to restore communication parameters (index 0x1000~0x1FFF) to default values
1014	0	Emergency message COB-ID	unsigned 32	RW	Define emergency object (EMCY) COB-ID, default value: 0x80 + Node-ID
1016	1	Consumer heartbeat time	unsigned 32	RW	Value definition: bits 31 ~ 24 reserved, bits 23 ~ 16 Node-ID, bits 15 ~ 0 heartbeat time (ms)
1017	0	Production End Heartbeat Time	unsigned 32	RW	Define Heartbeat Cycle Time (ms), Write 0 to Disable Heartbeat Function
1018	1	Supplier ID	unsigned 32	RO	Supplier ID, Inverter Manufacturer Value: 0x476 (Temporary Use)
	2	Product Code			Product Code
	3	Version Number			Version Number
1400	0	RPDO1 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default Value: 0x200 + Node-ID
	2	Transmission Type	unsigned 8	RW	Default Value: 5
1401	0	RPDO2 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default Value: 0x8000300 + Node-ID (Disable

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
					RPDO2)
	2	Transmission Type	unsigned 8	RW	Default Value: 5
1402	0	RPDO3 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x80000400 + Node-ID (Disable RPDO3)
	2	Transmission Type	unsigned 8	RW	Default Value: 5
1403	0	RPDO4 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x80000500 + Node-ID (Disable RPDO4)
	2	Transmission Type	unsigned 8	RW	Default Value: 5
1600	0	RPDO1 Mapping Parameters	unsigned 8	RO	Number of Mapped Objects (0~4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60400010, 0x6040-0x00 indicates the 16-bit control word in CiA 402 protocol
	2	Mapped Object 2	unsigned 32	RW	Default value:0x60420010, 0x6042-0x00 indicates the 16-bit status word in CiA 402 protocol
	3	Mapped Object 3	unsigned 32	RW	
	4	Mapped Object	unsigned	RW	

CM680 Inverter Communication Manual
CANopen Communication

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
		4	32		
1601	0	RPDO2 Mapping Parameters	unsigned 8	RO	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x20264110, 0x2026-0x41 indicates the 16-bit DO status setting value in Custom Protocol One
	2	Mapped Object 2	unsigned 32	RW	Default value:0x2026A110, 0x2026-0xA1 indicates the 16-bit AO1 ratio setting value in Custom Protocol One
	3	Mapped Object 3	unsigned 32	RW	Default value:0x2026A210, 0x2026-0xA2 indicates the 16-bit AO2 ratio setting value in Custom Protocol One
	4	Mapped Object 4	unsigned 32	RW	
1602	0	RPDO3 Mapping Parameters	unsigned 8	RO	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60400010, 0x6040 indicates the 16-bit control word in CiA 402 Protocol
	2	Mapped Object 2	unsigned 32	RW	Default value:0x607A0020, 0x6042 indicates the 32-bit target position in CiA 402 Protocol
	3	Mapped Object 3	unsigned 32	RW	Default value:0x60600008, 0x6042 indicates the 8-bit operation mode selection in CiA 402

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
					Protocol
	4	Mapped Object 4	unsigned 32	RW	
1603	0	RPDO4 Mapping Parameters	unsigned 8	RO	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60400010, 0x6040 indicates the 16-bit control word in CiA 402 Protocol
	2	Mapped Object 2	unsigned 32	RW	Default value:0x60710010, 0x6042 indicates the 16-bit target torque in CiA 402 Protocol
	3	Mapped Object 3	unsigned 32	RW	Default value:0x60600008, 0x6042 indicates the 8-bit operation mode selection in CiA 402 Protocol
	4	Mapped Object 4	unsigned 32	RW	
1800	0	TPDO1 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x180 + Node-ID
	2	Transmission Type	unsigned 8	RW	Default Value: 5
	3	Inhibition Time	unsigned 8	RW	PDO Transmission Minimum Interval, default value:0 (not used)
	5	Event Timer	unsigned 8	RW	Default value:0 (not used)

CM680 Inverter Communication Manual
CANopen Communication

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
1801	0	TPDO2 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x80000280 + Node-ID (TPDO2 disabled)
	2	Transmission Type	unsigned 8	RW	Default Value: 5
	3	Inhibition Time	unsigned 8	RW	PDO Transmission Minimum Interval, default value:0 (not used)
	5	Event Timer	unsigned 8	RW	Default value:0 (not used)
1802	0	TPDO3 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x80000380 + Node-ID (TPDO3 disabled)
	2	Transmission Type	unsigned 8	RW	Default Value: 5
	3	Inhibition Time	unsigned 8	RW	PDO Transmission Minimum Interval, default value:0 (not used)
	5	Event Timer	unsigned 8	RW	Default value:0 (not used)
1803	0	TPDO4 Communication Parameters	unsigned 8	RO	Maximum Supported Sub-index Count
	1	COB-ID	unsigned 32	RW	Default value:0x80000480 + Node-ID (TPDO4 disabled)

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
	2	Transmission Type	unsigned 8	RW	Default Value: 5
	3	Inhibition Time	unsigned 8	RW	PDO Transmission Minimum Interval, default value:0 (not used)
	5	Event Timer	unsigned 8	RW	Default value:0 (not used)
1A00	0	TPDO1 Mapping Parameters	unsigned 8	RW	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60410010, 0x6041-0x00 indicates the 16-bit status word in the CiA 402 protocol
	2	Mapped Object 2	unsigned 32	RW	Default value:0x60430010, 0x6043-0x00 indicates the 16-bit real-time target speed (rpm) in the CiA 402 protocol
	3	Mapped Object 3	unsigned 32	RW	
	4	Mapped Object 4	unsigned 32	RW	
1A01	0	TPDO2 Mapping Parameters	unsigned 8	RW	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x20260110, 0x2026-0x01 indicates the status of 16-bit DI terminals in Custom Protocol One
	2	Mapped Object 2	unsigned 32	RW	Default value:0x20266110, 0x2026-0x61 indicates the 16-bit AI1 ratio value in Custom

CM680 Inverter Communication Manual
CANopen Communication

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
					Protocol One
	3	Mapped Object 3	unsigned 32	RW	Default value:0x20266210, 0x2026-0x62 indicates the 16-bit AI2 ratio value in Custom Protocol One
	4	Mapped Object 4	unsigned 32	RW	Default value:0x20266310, 0x2026-0x63 indicates the 16-bit AI3 ratio value in Custom Protocol One
1A02	0	TPDO3 Mapping Parameters	unsigned 8	RW	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60410010, 0x6041-0x00 indicates the 16-bit status word in the CiA 402 protocol
	2	Mapped Object 2	unsigned 32	RW	Default value:0x60640020, 0x6064-0x00 indicates the 32-bit actual position in CiA 402 Protocol
	3	Mapped Object 3	unsigned 32	RW	Default value:0x60610008, 0x6061-0x00 indicates 8-bit operating mode in CiA 402 protocol
	4	Mapped Object 4	unsigned 32	RW	
1A03	0	TPDO4 mapping parameters	unsigned 8	RW	Number of Mapped Objects (0-4)
	1	Mapped Object 1	unsigned 32	RW	Default value:0x60410010, 0x6041-0x00 indicates the 16-bit status word in the CiA 402 protocol

Index (hex)	sub-Index (hex)	Name	Data format	Read/Write	Meaning
	2	Mapped Object 2	unsigned 32	RW	Default value:0x60770010, 0x6077-0x00 indicates 32-bit actual torque value in CiA 402 protocol
	3	Mapped Object 3	unsigned 32	RW	Default value:0x60610008, 0x6061-0x00 indicates 8-bit operating mode in CiA 402 protocol
	4	Mapped Object 4	unsigned 32	RW	

Table 62Fault Register Description

Bit	Description
0	General Fault
1	Current
2	Voltage
3	Temperature
4	Communication Fault
5	Device Protocol Specified
6	Reserved
7	Vendor Specified

6.3.4. Custom Protocol One

Table 63 Custom Protocol One

Index	Sub-Index	R/W	Data format	Meaning
0x2010+PrGroupNum 0x2070+PrGroupNum-0x E	PrNum+1	R/W	unsigned 16	Inverter Parameter Setting and Reading※
0x2020	0x01	R/W	unsigned 16	Control Command Word
	0x02	R/W	unsigned 16	Frequency Command (0.01Hz)
	0x03	R/W	unsigned 16	Trigger Command
0x2021	0x01	R	unsigned 16	Hbyte:warn code Lbyte:Error code
	0x02			Inverter operating status
	0x03			Frequency Command (0.01Hz)
	0x04			Output Frequency (0.01Hz)
	0x05			Output Current (0.1A)
	0x06			DC Bus Voltage (0.1V)
	0x07			Output Voltage (0.1V)
	0x08			Current multi-speed command segment
	0x09			Reserved
	0x0A			Display count value
	0x0B			Output power factor angle (0.1 degrees)
	0x0C			Output torque (0.1%)
	0x0D			Actual motor speed (rpm)
	0x0E			PG feedback pulse count (0-65535)
0x0F	PG2 pulse command count (0-65535)			
0x2022	0x01	R	unsigned 16	Output Current (0.01A), when current exceeds 655.36A, decimal place automatically switches to 1
	0x02			Display count value
	0x03			Output Frequency (0.01Hz)
	0x04			DC Bus Voltage (0.1V)
	0x05			Output Voltage (0.1V)
	0x06			Output power factor angle (0.1 degrees)

Index	Sub-Index	R/W	Data format	Meaning
	0x07			Three-phase Output Power (kW)
	0x08			Actual motor speed (rpm)
	0x09			Output torque (0.1%)
	0x0A			PG feedback pulse count (0-65535)
	0x0B			After PID Function Activation, Display PID Feedback Value (0.01%)
	0x0C			AI1 Terminal Input Value (0-100%)
	0x0D			AI2 Terminal Input Value (0-100%)
	0x0E			AI3 Terminal Input Value (0-100%)
	0x0F			Power Module IGBT Temperature (0.1°C)
	0x11			Digital Terminal Input Mode Selection (F5—15)
	0x12			Digital Terminal Output Mode Direction (F6—04)
	0x13			Current multi-speed command segment
	0x14			Digital Terminal Input Status (1: on)
	0x15			Digital Terminal Output Status (1: on)
	0x16			Motor Rotation Count (0—65535), Count Reset on Direction Change or Stop
	0x17			Pulse Input Frequency (PG2.0.01Hz)
	0x18			Pulse Input Position (PG2, 0—65535)
	0x1A			Overload Count (0.00-100.00%)
	0x1B			GFF Percentage Value (0.01%)
	0x1C			DC Bus Voltage (0.1V)
	0x1E			Synchronous Motor Pole Segment
	0x1F			User Physical Quantity Output
	0x20			Actual Output Frequency Gain Coefficient (0.01)
	0x21			Motor Rotation Count (Stop Hold, Reset Before Operation)
	0x22			Motor Running Position (Stop Hold, Reset Before Operation)
	0x25			Inverter Carrier Frequency (kHz)
	0x27			Inverter Status
	0x28			Output torque (0.1%)
	0x29			Torque Command (0.1%)
	0x2A			Energy Display (0.1kWh)
	0x2B			PG2 Pulse Input (highword)
	0x2C			PG2 Pulse Input (lowword)

CM680 Inverter Communication Manual
CANopen Communication

Index	Sub-Index	R/W	Data format	Meaning
	0x2D			Actual Motor Position (highword)
	0x2E			Actual Motor Position (lowword)
	0x2F			PID Reference Target (0.01%)
	0x30			PID Offset (0.01%)
	0x31			PID Output Frequency (0.01Hz)
0x206	0x01	R	unsigned 16	DI Terminal Input Status
	0x02	R	unsigned 16	Extended DI Terminal Input Status
	0x03-0x40	R	\	Reserved
	0x41	R/W	unsigned 16	DO Terminal Output Status
	0x42-0x60	R		Reserved
	0x61	R		AI1 Proportional Value
	0x62	R		AI2 Ratio Value
	0x63	R		AI3 Ratio Value
	0x64-0x6A	R		Reserved
	0x6B	R		Expansion Card AI10 Input Ratio Value
	0x6C	R		Expansion Card AI11 Input Ratio Value
	0xA1	R/W		AO1 Output Ratio Value
	0xA2	R/W		AO2 Output Ratio Value
	0xA3-0xAA	R/W		Reserved
	0xAB	R/W		Expansion Card AO10 Output Ratio Value
	0xAC	R/W		Expansion Card AO11 Output Ratio Value

※Note the mapping relationship between object dictionary and inverter function codes is as follows:

Object Dictionary Index = 0x2010 + Function Code Group Number (F0-FF Function Group);

or 0x2070 + Function Code Group Number (U0-L8 Function Group) - 0xE

Object Dictionary Sub-index = Function Code Group Internal Offset in Hexadecimal + 1;

Table 64Control Command Word Bit Definition:

Control Command Word	
bit 1-0	0: No Function
	1: Stop
	2: Start
	3: JOG Start
bit 3-2	Reserved

Control Command Word	
bit 5-4	0: No Function
	1: Forward Command
	2: Reverse Command
	3: Change Direction
bit 7-6	0: First Ramp
	1: Second Ramp
	2: Third Ramp
	3: Fourth Ramp
bit 11-8	0: Main Speed
	1-15: First to Fifteenth Segment Speed Selection
bit 12	1: Enable bit6-bit11 function
bit 15-13	Reserved

Table 65 Trigger Command Word Bit Definition

Trigger Command	
bit 0	1: External Fault (EF)
bit 1	1: Reset Command
bit 2	1: External Interrupt (BB)
bit 15-3	Reserved

Table 66 Inverter Operation Status Word Bit Definition

Inverter operating status	
bit 1-0	0: Stop
	1: Accelerating
	2: Standby
bit 2	JOG operation
bit 4-3	0: Forward
	1: Reverse to forward
	2: Forward to reverse
	3: Reverse
bit 7-5	Reserved
bit 8	1: Main frequency source is communication interface
bit 9	1: Main frequency source is analog input
bit 10	1: Main command source is communication interface

bit 11	1: Parameter lock
bit 12	1: Enable keypad parameter copy function
bit 15-13	Reserved

Table 67 Inverter status word bit definition

Inverter Status	
bit 1-0	0: No direction
	1: Forward
	2: Reverse
bit 3-2	0: Inverter Ready
	1: Inverter Fault
bit 4	1: Inverter Output 0: No Output
bit 5	1: Warning 0: No Warning

For the mapping relationship between terminal inputs/outputs and CANopen index, refer to 5.3 CANopen Analog AIO and DIO Description.

6.3.5 Custom Protocol Two

Table 68 Custom Protocol Two

Index	Sub-Index	R/W	Data format	Bit Definition		Speed Mode	Torque Mode
				bit	Meaning		
0x2060	0x01	R/W	unsigned 16	0	Ack	0: fcmd = 0 1: fcmd = fset	\
				1	Dir	0: Forward Command 1: Reverse Command	\
				2	Move	\	\
				3	Halt	0: Continue Running to Target Speed 1: Temporarily Stop According to Deceleration Settings	\
				4	Hold	0: Continue Running to Target Speed 1: Maintain Current Frequency	\
				5	JOG	0: OFF 1: RUN	\
				6	Qstop	Fast Shutdown	
				7	RUN	0: Shutdown 1: Startup	
				8	Multi-Speed Selection Bit	Multi-Speed Selection Bit 0	\
				9		Multi-Speed Selection Bit 1	\
10	Multi-Speed Selection Bit 2	\					

				11		Multi-Speed Selection Bit 3	\				
				12	Acceleration and Deceleration Time Selection Bit	Acceleration and Deceleration Time Selection Bit 0	\				
				13		Acceleration and Deceleration Time Selection Bit 1	\				
				14	Software Terminal Function Enable	Software Multi-Speed and Acceleration/Deceleration Time Switching Enable	\				
				15	Reset	Clear Fault Code					
				0x02	signed 32	0-15	Run Mode Command	0: Speed Mode	2: Torque Mode		
				0x03		0-15		Frequency Command (0.01Hz)	\		
				0x04		0-15		Torque Limit Value (0.01pu)			
				0x05		0-31	Reserved	Reserved			
				0x06	unsigned 16	0-15	Reserved	Reserved			
				0x07	signed 16	0-15		\	Torque Command		
				0x08	unsigned 16	0-15		\	Speed Limit		
				0x20 61		R	unsigned 16	0	Arrive	Frequency Command Arrival	Torque Command Arrival
								1	Dir	0: Forward 1: Reverse	
								2	Warn	Warning Occurred	
3	Error	Fault Occurred									
4	Reserved	Reserved									
5	JOG	JOG operation									
6	Qstop	Fast Shutdown									
7	PowerOn	Excitation									
15-8	Reserved	Reserved									
0x02	0-15	Reserved	Reserved								
0x03	0-15	Frequency	Actual Output Frequency								
0x04	0-15	Reserved	Reserved								
0x05	signed 32	0-31	Reserved					Reserved			
0x06	unsigned 16	0-15	Reserved					Reserved			
0x07	signed 16	0-15	Torque					Actual Torque			

6.3.6 CiA 402

Table 69 CiA 402 Supported Index

Index	Sub-Index	Definition	Default Value	R/W	Data format	Unit	PDO Mapping
0x6007	00h	Communication Exception Action Selection	2	R/W	signed 16	\	Yes
0x603F	00h	CANopen Fault Code	0	RO	unsigned 16	\	Yes
0x6040	00h	Control Word	0	R/W	unsigned 16	\	Yes
0x6041	00h	Status Word	0	RO	unsigned 16	\	Yes
0x6042	00h	Target Speed (vl)	0	R/W	signed 16	rpm	Yes
0x6043	00h	Actual Target Speed (vl)	0	RO	signed 16	rpm	Yes
0x6044	00h	Actual Speed (vl)	0	RO	signed 16	rpm	Yes
0x604F	00h	First Acceleration Time (vl)	10000	R/W	unsigned 32	ms	Yes
0x6050	00h	First Deceleration Time (vl)	10000	R/W	unsigned 32	ms	Yes
0x6051	00h	Rapid Stop Time (vl)	0	R/W	unsigned 32	ms	Yes
0x605A	00h	Rapid Stop Option	2	R/W	signed 16	\	No
0x605C	00h	Stop Option	1	R/W	signed 16	\	No
0x6060	00h	Operation Mode Selection	2	R/W	signed 8	\	Yes
0x6061	00h	Operation Mode Display	2	RO	signed 8	\	Yes
0x6064	00h	Actual Position Value (pp)	0	RO	signed 32	\	Yes
0x 6071	00h	Target Torque (tq)	0	R/W	signed 16	0.001	Yes
0x 6072	00h	Maximum Torque (tq)	150	R/W	unsigned 16	0.001	No
0x 6075	00h	Motor Rated Current (tq)	0	RO	unsigned 32	mA	No
0x 6077	00h	Actual Torque Value (tq)	0	RO	signed 16	0.1%*	Yes
0x 6078	00h	Actual Current Value (tq)	0	RO	signed 16	0.1%*	No
0x 6079	00h	DC bus voltage (tq)	0	RO	unsigned 32	mV	Yes
0x 607A	00h	Target position (PP)	0	R/W	signed 32	\	Yes

*: Motor rated values are 100%

Control word (6040h-00h) bit definitions are as follows:

15		11	10	9	8	7	6	4	3	2	1	0
ms		r	oms	h	fr	oms		eo	qs	ev	so	

MSB

LSB

Note: ms = manufacture-specific; r = reserved; oms = operation mode specific; h = halt;
 fr = fault reset; eo = enable operation; qs = quick stop; ev = enable voltage; so = switch on

Status word (6041h-00h) bit definitions are as follows:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ms		oms		ila	tr	rm	ms	w	sod	qs	ve	f	oe	so	rtso

MSB LSB

Note:ms = manufacture-specific; oms = operation mode specific; lia = internal limit active; tr = target reached; rm = remote; w = warning; sod = switch on disable; qs = quick stop;
 ve = voltage enable; f = fault; oe = operation enable; so = switch on; rtso = ready to switch on

Status word encoding mapping table is as follows:

Table 70 Status Word Encoding Table

statusword	PDS FSA state
xxxx xxxx x0xx 0000b	Not ready to switch on
xxxx xxxx x1xx 0000b	Switch not disabled
xxxx xxxx x01x 0001b	Ready to switch on
xxxx xxxx x01x 0011b	Switched on
xxxx xxxx x01x 0111b	Operation enabled
xxxx xxxx x00x 0111b	Quick stop active
xxxx xxxx x0xx 1111b	Fault reaction active
xxxx xxxx x0xx 1000b	Fault

6.4. CANopen Control Inverter Function Debugging

Preparations for Controlling the Inverter via CANopen are as follows:

1. Wiring, refer to 2.2 CAN Wiring Method
2. Set the frequency command source, parameter F0-06 = 6, select the frequency command source as CANopen setting.
3. Set the operation command source, parameter F0-05 = 3, select the operation command source as CANopen setting.
4. Set the CANopen slave station node address, parameter F8-14 sets the slave station address (default value is 0, indicating the slave station function is disabled, 1~127 are valid slave station node addresses). After setting the slave station node address, if a station number error or CANopen memory error is reported, the CANopen can be reset by setting parameter F0-18 = 7.
5. Set the CAN communication speed, parameter F8-15 sets the CANopen communication speed, parameter value setting range 0 (1Mbps), 1 (500kbps), 2 (250kbps), 3 (125kbps), 4 (100kbps), 5 (50kbps).
6. The master station uses NMT to control the slave station to enter the operational mode.

6.4.1. CANopen selects the CiA 402 protocol.

Under the CiA 402 protocol, speed mode and torque mode are supported. Setting parameter F8-19 = 1 enables the CiA 402 protocol. To enable the fast shutdown function with external terminals, set one of the parameters F5-00~F5-07 or LC-00~LC-02 to 53.

6.4.1.1. Speed Mode

The debugging steps are as follows:

1. Set the operation mode at index 6060h-00h to 2, configuring the inverter to speed mode.
2. The control command word controls the inverter to enter the operational enable state; send the control command word 0x0E at index 6040h-00h, then send 0x0F to enable the inverter to enter the operational enable state. Note the control of the bits 6~4 of the control command word, defined as follows:

Table 71 Control Command Word Bits 6~4

Bit 6	bit 5	bit 4	Function
1	0	1	Run at the current frequency
1	1	1	Run to target
x	x	x	Decelerate to 0Hz

4. Set the target speed, set the target speed at index 6042h-00h, unit is rpm, set a positive value for forward rotation, a negative value for reverse rotation. Note the relationship between motor speed and frequency (information on the number of motor pole pairs).

5. Set acceleration and deceleration time, set the inverter acceleration and deceleration time at indices 604Fh-00h and 6050h-00h, unit is ms.

6. Get the current operating speed, read index 6043h-00h to obtain the current operating speed, unit is rpm.

6.4.1.2. Torque Mode

The debugging steps are as follows:

1. Set index 6060h-00h to 4, setting the inverter to torque mode, at this time 6042h-00h is used to set the speed limit.

2. The control command word controls the inverter to enter the operational enable state; send the control command word 0x0E at index 6040h-00h, then send 0x0F to enable the inverter to enter the operational enable state.

3. Set the target torque, index 6071h-00h sets the target torque, index 6072h-00h sets the maximum torque.

4. Get the current torque, read index 6077h-00h to obtain the current torque, unit 0.1%.

6.4.2. CANopen selects the inverter manufacturer's custom protocol

Parameter F8-19 = 0 enables the inverter manufacturer's custom protocol.

6.4.2.1. Custom Protocol One

The custom protocol only supports speed mode. Debugging steps are as follows:

1. Parameter F8-07 = 0 enables custom protocol one.
2. Set target frequency, index 2020h-02 sets the target frequency, unit is 0.01Hz, for example, 5000 represents 50Hz.
3. Operation control, index 2020h-01h set to 2 for operation, index 2020h-01h set to 1 for shutdown.

6.4.2.2. Custom Protocol Two

Custom Protocol Two supports speed mode and torque mode.

- Speed Mode Debugging Steps are as follows:

1. Parameter F8-07 = 1 enables Custom Protocol Two.
2. Set target frequency, index 2060h-03 sets the target frequency, unit is 0.01Hz, for example, 5000 represents 50Hz.
3. Operation control, index 2060h-01h set to 80h for excitation, index 2060h-01h set to 81h for operation.

- Torque Mode Debugging Steps:

1. Parameter F8-07 = 1 enables Custom Protocol Two.
2. Set the target torque, index 2060h-07 sets the target torque, unit is 0.1%, for example, 1000 represents 100%.
3. Operation Control, set index 2060h-01h to 80h for excitation, after the inverter is excited, it automatically runs to the target torque.
4. Get Current Torque, read index 2061h-07h to obtain the current torque, unit is 0.1%.

Note: In Torque Mode, if the speed reaches the limit value, the inverter may reduce the output torque to ensure the speed remains within the limit.

6.4.3. Analog AIO and DIO

The inverter can simulate the status of IO ports through CANopen data, achieving software simulation of AO (Analog Output) and DO (Digital Output) functions, and can obtain the status of AI (Analog Input) and DI (Digital Input) and send it to the CAN bus. CANopen index and DIO (Digital input and output) and AIO (Analog input and output) mapping table as follows: DI terminal (physical terminal name MI, Multi-function input) and CANopen index (2026h-01h) data bit mapping table:

Table 72 DI terminal and CANopen index data bit mapping table

Terminal Name	Attribute	bit
FWD	RO	bit 0
REV	RO	bit 1
MI 1	RO	bit 2
MI 2	RO	bit 3

Terminal Name	Attribute	bit
MI 3	RO	bit 4
MI 4	RO	bit 5
MI 5	RO	Bit 6
MI 10	RO	bit 10
MI 11	RO	bit 11
MI 12	RO	bit 12

DO terminal (physical terminal name MO, Multi-function output) and CANopen index (2026h-41h) data bit mapping table:

Table 73 DO terminal and CANopen index data bit mapping table

Terminal Name	Parameter Setting	Attribute	bit
RY 1	02-13 = 50	RW	bit 0
RY 2	02-14 = 50	RW	bit 1
MO 1	02-16 = 50	RW	bit 3
MO 2	02-17 = 50	RW	bit 4
MO 10	02-36 = 50	RW	bit 5
MO 11	02-37 = 50	RW	Bit 6
MO 12	02-38 = 50	RW	bit 7

AI Terminal (Physical Terminal Names AI1, AI2, AI3, Analog Input) and CANopen Index (2026h) Data Bit Mapping Table:

Table 74 AI Terminal and CANopen Index Data Bit Mapping Table

Terminal Name	Attribute	sub-index
AI1	RO	61h
AI2	RO	62h
AI3	RO	63h
AI 10	RO	64h
AI 11	RO	65h

AO Terminal and CANopen Index (2026h) Data Bit Mapping Table:

Table 75 AO Terminal and CANopen Index Data Bit Mapping Table

Terminal Name	Parameter Setting	Attribute	sub-index
AO 1	03-20 = 20	RW	A1h
AO 2	03-23 = 20	RW	A2h
AO 10	14-12 = 20	RW	A3h
AO 11	14-13 = 20	RW	A4h

Taking CANopen control of AO and DO as an example, the parameter configuration steps are as follows:

- Set parameter F6-14 = 20, AO1 is defined as controlled by CANopen index 2026h-A1h, controlling the data of index 2026h-A1h can control the output voltage value of AO1. If you want to control AO1 to output 6V voltage (duty = 60%), you need to set index 2026h-A1h to 6000.
- Set parameter F6-00 = 50, RY1 is defined as controlled by bit 0 of CANopen index 2026h-41h, controlling the bit 0 of index 2026h-41h data can control the ON/OFF state of RY1. If you want to control RY1 to output ON, you need to set bit 0 of index 2026h-41h to 1.

6.5. CANopen Fault Code

Fault codes can be read through object 0x603F, and fault types can be read through object 0x1001. Fault codes xx80h~xxFFh and FF00h ~ FFFFh are manufacturer-defined.

Table 76 CANopen Fault Codes

Fault Code	Meaning
2213h	Overcurrent during acceleration and deceleration

CM680 Inverter Communication Manual
CANopen Communication

Fault Code	Meaning
2240h	Ground fault
2250h	Short circuit fault
2310h	Continuous overcurrent
2314h	Overcurrent at constant speed
2331h	U phase output missing
2332h	V phase output missing
2333h	W Phase Output Phase Loss
3130h	Input Phase Loss
3210h	DC Bus Overvoltage
3220h	DC Bus Undervoltage
3330h	Motor Connection Switching Error
4310h	Inverter Overtemperature
5530h	EEPROM Abnormal
7301h	PG Feedback Abnormal
7320h	Position Out of Limit
7500h	Modbus Communication Fault
8100h	CANopen Software Fault
8130h	CANopen Communication Timeout
8140h	CANopen Disconnection
8311h	Over Torque Fault
8321h	Current Underflow
8A00h	Low Frequency Overload Protection

Fault Code	Meaning
9000h	External Trigger Fault
FF00h	IGBT Temperature Detection Abnormal (th1o)
FF01h	Capacitor temperature detection abnormal (th2o)
FF04h	U phase current detection error (cd1)
FF05h	V phase current detection error (cd2)
FF06h	W phase current detection error (cd3)
FF07h	CBC hardware circuit abnormal (hd0)
FF08h	OC hardware circuit abnormal (hd1)
FF20h	Motor overheating (oh3)
FF21h	Motor auto-identification error (AUE)
FF22h	PID feedback disconnection
FF25h	AI Disconnection (ACE)
FF26h	Password Input Incorrect Three Times (Pcod)
FF27h	Deceleration Energy Regeneration Action (dEb)
FF28h	Over Slip (oSL)
FF29h	PG Card Hardware Error (PGF5)
FF2Bh	U Phase Short Circuit Detected Before Operation (Aoc)
FF2Ch	V Phase Short Circuit Detected Before Operation (boc)
FF2Dh	W Phase Short Circuit Detected Before Operation (coc)
FF30h	S1 Internal Loop Diagnosed with Abnormality (STL1)
FF31h	STO (STO)
FF32h	S2 Internal Loop Diagnostics Detected an Abnormality

Fault Code	Meaning
	(STL2)
FF33h	Internal Loop Diagnostics Detected an Abnormality (STL3)
FF3Dh	Motor Auto-Identification Error (DC Test Phase) (AuE1)
FF3Eh	Motor Auto-Identification Error (High-Frequency Stall Phase) (AuE2)
FF3Fh	Motor Auto-Identification Error (Rotation Test Phase) (AuE3)

Fault Type Data Bit Definitions Are as Follows:

bit	Meaning
0	General Fault
1	Current
2	Voltage
3	Temperature
4	Communication Fault
5	Device Sub-Protocol Specified
6	Reserved
7	Vendor Specified

6.6. Communication Configuration

For Example, to Configure the Module to Establish CANopen Communication with the PLC. The configuration process varies for different PLC models; please consult technical support for details.

6.6.1. Configure Configuration

1. Create a project

Double-Click to Open the Host Computer Programming Software, Click on 'New Project'. Select the PLC Device Type and Programming Language, Change the Save Path and Project Name, Then Click 'OK'.

Enter the 'Network Configuration' interface, click the PLC icon, and check 'CANopen Master Station'.

2. Install EDS File

If the EDS file has not been installed before, it needs to be installed first. Enter the 'Network Configuration' interface, click 'Import EDS File', find the path where the EDS file is stored, and click 'Open'.

After the EDS file is successfully installed, you can find the CANopen device in the network device list — CANopen port — third-party manufacturers — SUYNE.

3. Configure Slave Station

In the network device list, find the CANopen module, double-click to add the module.

In the 'Device' list, under 'CANopen', find the module device, double-click to enter the configuration interface. In the 'Slave Parameter Configuration' page, check 'Enable Expert Mode' to open more configuration options.

In the 'Slave Station Parameter Configuration' page, the node ID can be configured, and the value must be consistent with the inverter F8-14 setting.

In the 'CANopen Master Station' page, the baud rate can be configured, and the value must be consistent with the inverter F8-15 setting.

6.6.2. Configure Periodic Communication

1. Configure RPDO

The EMH-OP Communication Expansion Card supports 4 RPDO transmissions, with a maximum of 16 register data transmissions.

2. Configure TPDO


The EMH-OP Communication Expansion Card supports 4 TPDO transmissions, with a maximum of 16 register data transmissions.

After configuration is complete, download the configuration, and the PLC and module will automatically perform periodic data exchange.

6.6.3. Configure Non-periodic Communication


1. SDO Read Operation

The module supports the fast SDO transfer mechanism, with each data transmission length being 0~4 bytes. The SDO_READ4 function block of the PLC can achieve SDO read operations.



2. SDO Write Operation

The SDO_WRITE4 function block of the PLC can achieve SDO write operations.



7. Appendix Periodic General Fault Codes

Table 77 Periodic General Fault Codes

Diagnostic Classification	Status Code
Inverter Body Diagnostic Information (Register Address: 0x2100)	Low Byte (Fault Error Code):
	0 No Abnormal Record
	1 Overcurrent During Acceleration
	2 Overcurrent During Deceleration
	3 Overcurrent During Constant Speed
	4 Ground Short Circuit
	5 IGBT Upper and Lower Bridge Short Circuit
	6 Overcurrent During Stop
	7 Overvoltage During Acceleration
	8 Overvoltage During Deceleration
	9 Overvoltage During Constant Speed
	10 Overvoltage During Stop
	11 Undervoltage During Acceleration
	12 Undervoltage During Deceleration
	13 Undervoltage During Constant Speed
	14 Undervoltage during Stop
	15 Input Phase Loss Protection
	16 IGBT Overtemperature
	17 Ambient Overtemperature
	21 Inverter Overload
	22 Motor 1 Overload Protection
	23 Motor 2 Overload Protection
	24 Motor Overheat
	26 Over Torque 1
	27 Over Torque 2
	28 Low Current
	29 Limit Reached
	31 Memory Read Error
	33 U Phase Current Detection Error
	34 V Phase Current Detection Error
	35 W Phase Current Detection Error
	36 cc Hardware Circuit Abnormality
	37 oc Hardware Circuit Abnormality
	38 ov Hardware Circuit Abnormality
	40 Motor Parameter Identification
	55 Illegal Communication Address
	56 Communication Data Error
	57 Communication Write to Read-Only Address
	58 Modbus Transmission Timeout
	62 Deceleration Regenerative Braking Action
63 Excessive Slip	
64 Please Reset Machine Code	
65 PG Card Hardware Error	
69 Feedback Speed Divergence	
70 Feedback Speed Deviation Excessive	
72 STO1 Fault	
76 STO	
77 STO2 Fault	
79 U Phase Overcurrent	
80 V Phase Overcurrent	
81 W Phase Overcurrent	
82 U Phase Output Phase Loss	
83 V Phase Output Phase Loss	
84 W Phase Output Phase Loss	
87 Low Frequency Overload Protection	
101 CANopen Disconnection 1	
102 CANopen Disconnection 2	
104 CANopen Hardware Disconnection	
105 CANopen Index Error	
106 CANopen Station Number Error	
107 CANopen Memory Error	
120 EMS Overcurrent	
128 Over Torque 3	
129 Over Torque 4	
134 Motor 3 Overload Protection	
135 Motor 4 Overload Protection	
141 Ground Fault Before Operation	
142 Parameter Identification Error 1	

CM680 Inverter Communication Manual
Periodic General Fault Codes

	Error	143	Parameter Identification Error 2
41	PID Disconnection	144	Tension Band Break
42	PG Feedback Setting Error	147	Tension PID Deviation Too Large
43	PG Feedback Disconnection		
44	PG Feedback Stall		
45	PG Slip Abnormality		
48	AI Current Signal Disconnection		
49	External Fault		
50	External Terminal Emergency Stop		
51	External Interruption		
52	Password Input Incorrect Three Times (Pcod)		
54	Illegal Communication Command		
	High Byte (Warn Warning Code):		
0	No Abnormal Record		
1	Communication Command Error		
2	Communication Address Error		
3	Communication Data Error		
4	Inverter Unable to Process		
5	Communication Transmission Timeout		
7	Parameter Copy Error		
8	Parameter Copy Error		
9	IGBT Overheat Warning		
11	PID Feedback Signal Warning		
12	AI Current Signal Disconnection		
15	PG Feedback Error		
17	Overspeed Warning		
18	Speed Deviation Too Large		
19	Input Phase Loss		
20	Over Torque 1		
21	Over Torque 2		
22	Motor Overheat		
24	Over Slip		
25	Parameter Identification In Progress		
28	Output Phase Loss Warning		
30	Different Model Parameter Copy Error		
31	Over Torque 3		
32	Over Torque 4		
36	CANopen Software Disconnection 1		
37	CANopen Software Disconnection 2		
39	CANopen Hardware Disconnection		
40	CANopen Index Error		

	41	CANopen Station Number Error
	42	CANopen Memory Error

8. Appendix Modbus Communication

8.1. Communication Introduction

The CM680 series inverter uses an RS485 communication interface to connect with a PC/PLC for communication, forming a single-master multiple-slave PC/PLC communication network. Each communication slave must have a unique slave address, with the setting range for the slave address being 1 to 254, and 0 being the broadcast communication address. Users can control slaves (inverters) centrally through the master (usually a PC or PLC), achieving functions such as setting inverter operation commands, modifying and reading parameters, and reading inverter operating status and fault information through the Modbus communication protocol.

The CM680 series inverter supports Modbus-ASCII and Modbus-RTU slave station communication protocols. This communication protocol is a serial communication protocol that defines the content and format of information transmitted in serial communication. If the slave station encounters an error during information reception or cannot execute the command issued by the master station, the slave station will send a fault information back to the master station.

8.2. RS485 Connection Topology

The RS485 bus typically uses a daisy chain topology, where the 485+ interfaces of the master station and multiple slave stations are connected in sequence, and the 485- interfaces are connected similarly. The daisy chain topology of the RS485 bus is shown in Figure 1. The daisy chain topology has advantages such as low signal reflection, high communication success rate, and no need for additional equipment. To reduce the impact of interference on the output signal, it is recommended to use shielded twisted pair cables for RS485 bus transmission.




Figure 1 Daisy Chain RS485 Bus Topology

8.3. Communication Transmission Method

The RS485 communication protocol supports both half-duplex and full-duplex modes. In most cases, we use the half-duplex mode, where at any given time, only one device (master or slave) can transmit data while the other can only receive data. The RS485 communication transmission method is shown in Figure 3. Data is transmitted in the form of messages as specified in the Modbus-RTU protocol. One frame of data is sent at a time, and a new communication frame begins when the idle time on the communication line exceeds the transmission time of 3.5 bytes.




Figure 2 RS485 Communication Transmission Method

The CM680 Inverter is equipped with Modbus-RTU and Modbus-ASCII communication protocols, allowing users to choose which protocol to use. In the network, only one device (the master) can establish the protocol, that is, issue a “query/command.” Other devices (slaves) can only respond to the

master's "query/command" and provide data, or perform the corresponding operations as directed by the master. The master can be a PC, PLC, etc., and the slave refers to the inverter. The master can communicate independently with a specific slave or broadcast information to all slaves. When the master sends a "query/command," the slave must return a response, but if the master sends a broadcast message, the slave does not need to respond.

8.4. Communication Data Frame Structure

The Modbus-RTU protocol communication data format is shown in Figure 4, the inverter only supports read or write operations for Word-type parameters, the corresponding communication read command is 03; the write command is 06, the multiple write command is 10, and byte or bit read/write operations are not supported.




Figure 3(a) Master Station Read Command Frame

Note: Theoretically, the host can read multiple consecutive parameters at once (i.e., n can be up to 12), but it should be noted that it cannot exceed the last parameter of the current parameter group, otherwise, an error response will be returned.




Figure 3(b) Slave Station Read Response Frame




Figure 3(c) Master Station Write Command Frame




Figure 3(d) Slave Station Write Response Frame

CM680 Inverter Communication Manual
Modbus Communication




Figure 3(e) Master Station Multiple Write Command Frame

Note: Multiple writes and multiple reads are the same, with a maximum of 12 parameters that can be operated.




Figure 3(f) Slave Station Multiple Write Response Frame

The read response error command for the slave station is 0x83, the write response error command is 0x86, the multiple write response error command is 0x90, and CRC check errors do not respond. In addition, in the error types, 0x01 indicates command code error, 0x02 indicates address error, 0x03 indicates data error, and 0x04 indicates the command cannot be processed.




Figure 3(g) Slave Station Read Error Response Frame




Figure 3(h) Slave Station Write Error Response Frame




Figure 3(i) Slave Station Multiple Write Error Response Frame

8.5. Related Parameters

Function Code	Name	Content	Default Value	Parameter Description
F8-00	Baud Rate Setting	4.8~115.2 kb/s	115.2	Used to set the

Function Code	Name	Content	Default Value	Parameter Description
				data transfer rate between the host computer and the inverter. The higher the baud rate, the faster the communication. Note: The baud rate set on the host computer and the inverter must be the same, otherwise communication cannot be performed.
F8-01	Communication Data Format	0: 7,N,1 for ASCII 1: 7,N,2 for ASCII 2: 7,E,1 for ASCII 3: 7,O,1 for ASCII 4: 7,E,2 for ASCII 5: 7,O,2 for ASCII 6: 8,N,1 for ASCII 7: 8,N,2 for ASCII 8: 8,E,1 for ASCII 9: 8,O,1 for ASCII 10: 8,E,2 for ASCII 11: 8,O,2 for ASCII 12: 8,N,1 for RTU 13: 8,N,2 for RTU 14: 8,E,1 for RTU 15: 8,O,1 for RTU 16: 8,E,2 for RTU 17: 8,O,2 for RTU	12	The data format set by the master station and the inverter must be consistent; otherwise, communication cannot proceed.
F8-01	Communication Data Format	0: 7,N,1 for ASCII 1: 7,N,2 for ASCII 2: 7,E,1 for ASCII 3: 7,O,1 for ASCII 4: 7,E,2 for ASCII 5: 7,O,2 for ASCII 6: 8,N,1 for ASCII 7: 8,N,2 for ASCII 8: 8,E,1 for ASCII 9: 8,O,1 for ASCII 10: 8,E,2 for ASCII 11: 8,O,2 for ASCII 12: 8,N,1 for RTU 13: 8,N,2 for RTU 14: 8,E,1 for RTU 15: 8,O,1 for RTU 16: 8,E,2 for RTU 17: 8,O,2 for RTU	12	The data format set by the master station and the inverter must be consistent; otherwise, communication cannot proceed.
F8-02	Communication Address	1~254	1	Used to set the communication address of the inverter.
F8-03	Response Delay	0.0~200.0ms	2.0	The interval time between the end of data reception by the inverter and the sending of data to the master station. If the response delay is less

CM680 Inverter Communication Manual
Modbus Communication

Function Code	Name	Content	Default Value	Parameter Description
				than the system processing time, the response delay will be based on the system processing time; If the response delay is greater than the system processing time, the system will delay sending data to the master station until the response delay time is reached.
F8-04	Communication Timeout Time	0.0~100.0s	0.0	When this parameter is set to a non-zero value, if the interval between one communication and the next exceeds the communication timeout time, the system will report a Modbus transmission timeout (E058) fault. In most cases, it is set to zero, which means it is invalid.

8.6. Communication Parameter Address

This section contains the communication content, used for controlling the inverter's operation, inverter status, and related parameter settings. R indicates read-only, and RW indicates read-write.

The parameter address is indicated by the function code group number and label:

High Byte: F0~FF groups are 0x00~0x0F, U0~U1 are 0x10~0x11, H1~H3 are 0x12~0x15, L0~L8 are 0x16~0x1E.

Low Byte: 0x00~0xFF

For example, address F0-11 is represented as 0x000B

Note:

FF Group: Neither readable nor writable parameters; U Group: Read-only, not writable parameters.

Some parameters cannot be modified when the inverter is in operation; some parameters cannot be modified regardless of the inverter's state. When changing function code parameters, pay attention to the parameter range, unit, and related notes.

Function Code Group Number	Communication Access Address
F0~FE Groups	0x0000~0x0FFF
U0~U1 Groups	0x1000~0x11FF
H1~H3 Groups	0x1200~0x15FF
L0~L8 Groups	0x1600~0x1EFF

20xx Definition:

Address	Parameter Description	Address	Parameter Description
2102H	Given Frequency (Unit: 0.01Hz)	2210H	DI Switch Status, Read-Only
2103H	Output Frequency (Unit: 0.01Hz), Read-Only	2211H	DO Switch Status, Read-Only
2200H	Output Current (Unit: A), Read-Only	2212H	Multi-Speed, Read-Only
2201H	Count Value, Read-Only	2213H	DI CPU Pin Status, Read-Only
2202H	Actual motor speed (unit: rpm), read-only	2214H	DO CPU pin status, read-only
2203H	Bus voltage (unit: V), read-only	2215H	PG1 encoder pulse count, read-only
2204H	Output voltage (unit: V), read-only	2216H	Pulse input frequency (unit: Hz), read-only
2205H	Power factor angle (unit: deg), read-only	2217H	Pulse input position, read-only
2206H	Output power (unit: kW), read-only	221AH	GFF Detection Percentage (Unit: %)
2207H	Actual Feedback Speed (Unit: rpm), Read-Only	221EH	User-Defined Display
2208H	Output Torque (Unit: Nm), Read-Only	2223H	Speed Mode, Read-Only
2209H	PG Position, Read-Only	2224H	Carrier Frequency (Unit: Hz), Read-Only
220AH	PID Feedback Value, Read-Only	222CH	PG1 Pulse Low Byte (Unit: 1Hz), Read-Only
220BH	AI1, read-only	222DH	PG1 pulse high word (unit: 0.01Hz), read-only
220CH	AI2, read-only	222EH	PID setpoint, read-only
220DH	AI3, read-only	222FH	PID compensation, read-only
220EH	IGBT temperature (unit: °C), read-only	2230H	PID output frequency (unit: Hz), read-only
220FH	Bus capacitor temperature (unit: °C), read-only		

Stop/Run Parameters Section:

Type	Command Address	Command Content
Control Command Input (Write Only)	2000H	xx12: Forward Operation xx22: Reverse Operation xx13: Forward Jog xx23: Reverse Jog xxx1: Stop Operation
Set Frequency (Read/Write)	2001H	Set Frequency (Unit: 0.01Hz)

Type	Command Address	Command Content
		xx25:oc Hardware Circuit Abnormality xx80:Over Torque 3
		xx26:ov Hardware Circuit Abnormality xx81:Over Torque 4
		xx28:Motor Parameter Identification Error xx86:Motor 3 Overload Protection
		xx29:PID Disconnection A12 xx87:Motor 4 Overload Protection
		xx2A:PG Feedback Setting Error xx8D:Pre-Operation Ground Fault
		xx2B:PG Feedback Disconnection xx8E:Parameter Identification Error 1
		xx2C:PG Feedback Stall xx8F: Parameter Identification Error 2
		xx2D: PG Slip Abnormality xx92: Broken Belt Detection
		xx31: External Terminal Abnormality xx93: Tension PID Feedback Error Detection
		xx32: External Terminal Emergency Stop
		01xx: Communication Command Error 16xx: Motor Overheating
		02xx: Communication Address Error 18xx: Over Slip
		03xx: Communication Data Error 19xx: Parameter Identification In Progress
		04xx: Inverter Unable to Process 1Cxx: Output Phase Loss Warning
		05xx: Communication Transmission Timeout 1Exx: Different Model Copy Error
		07xx: Parameter Copy Error 1Fxx: Over Torque 3
		08xx: Parameter Copy Error 20xx: Over Torque 4
		09xx:IGBT Overheat Warning 24xx:CANopen Software Disconnection
		0Axx:Environmental Overheat Warning 25xx:CANopen Software Disconnection
		0Bxx:PID Feedback Signal Warning 27xx:CANopen Hardware Disconnection
		0Dxx:Low Current Warning 28xx:CANopen Index Error
		0Fxx:PG Feedback Error 29xx:CANopen Node Address Error
		11xx:Overspeed Warning 2Axx:CANopen Memory Error
		12xx:Excessive Speed Deviation 2Bxx:CANopen SDO Transmission Timeout
		13xx:Input Phase Loss 2Cxx:CANopen SDO Reception Overflow
		14xx:Over Torque 12Dxx:CANopen Initialization Error
		15xx:Over Torque 22Exx:CANopen Format Error

60xx definition

command address	bit	bit name	value	Parameter Description
-----------------	-----	----------	-------	-----------------------

CM680 Inverter Communication Manual
Modbus Communication

command address	bit	bit name	value	Parameter Description
6000h (RW)	0	CMD_ACT	0	fcmd =0
			1	fcmd = Fset(Fpid)
	1	EXT_CMD1	0	forward direction command
			1	reverse direction command
	2	-	-	-
	3	HALT	0	continue to target speed
			1	temporarily stop according to deceleration settings
	4	LOCK	0	continue to target speed
			1	Maintain Current Frequency
	5	JOG	0	JOG OFF
			Pulse 1	JOG RUN
	6	QSTOP	0	None
			1	Quick Stop
	7	SERVO_ON	0	Servo OFF
			1	Servo ON
	11~8	GEAR	0000	Main Speed
			0001~ 1111	1~15 Segment Speed Frequency Switching
	13~12	ACC/DEC	00	First Segment Acceleration/Deceleration Time
			01	Second Segment Acceleration/Deceleration Time
			10	Third Segment Acceleration/Deceleration Time
11			Fourth Segment Acceleration/Deceleration Time	
14	EN_SW	0	Do Not Allow Multi-Segment Command and Acceleration/Deceleration Time Switching	
		1	Allow Multi-Segment Command and Acceleration/Deceleration Time Switching	
15	RST	Pulse 1	Clear Error Code	
6002h (RW)	15-0	Velocity Cmd		Frequency Command (0.01Hz)
6100h (R)	0	ARRIVE	0	Frequency Command Not Reached
			1	Frequency Command Arrival
	1	DIR	0	Forward
			1	Reverse
	2	WARN	0	No Warning
			1	Warning Occurred
	3	ERROR	0	No Error
			1	Error Occurred
	5	JOG	0	None
			1	On JOG
	6	QSTOP	0	None
			1	On Quick Stop
	7	SERVO_ON	0	PWM OFF
			1	PWM ON
8	Ready	0	Ready OFF	
		1	Ready ON	
15-9	-	-	-	
6102h (R)	15-0	Velocity cmd		Actual Output Frequency